




Installation and operation manual

Fan coil units



FWQ04AA
FWQ05AA
FWQ07AA
FWQ09AA
FWQ11AA
FWQ14AA
FWQ17AA
FWQ20AA
FWQ25AA

Installation and operation manual
Fan coil units

English

Table of contents

1 About the documentation	3
1.1 About this document.....	3
1.2 Meaning of warnings and symbols	3
1.3 General.....	4
2 Specific installer safety instructions	4
For the installer	5
3 About the box	5
3.1 To unpack and handle the fan coil unit.....	5
3.2 To remove the accessories from the fan coil unit.....	5
4 About the units and options	6
4.1 Identification	6
4.1.1 Identification label: Fan coil unit.....	6
5 Unit installation	6
5.1 Preparing the installation site	6
5.2 Interchangeability	7
5.3 Mounting the unit.....	8
5.3.1 To install the suspension bolts.....	8
5.3.2 To mount the unit.....	8
5.4 Water piping installation	9
5.4.1 Preparing water piping	9
5.4.2 Connecting water piping	10
5.5 Drain piping installation	10
5.5.1 Guidelines when installing the drain piping.....	10
5.5.2 Connecting the drain piping	11
5.6 Optional equipment installation	11
5.6.1 Preparing of optional equipment	11
6 Electrical installation	12
6.1 Preparing electrical wiring	12
6.2 Connecting the electrical wiring.....	13
7 Configuration	14
7.1 DIP switch positioning	14
8 Commissioning	14
8.1 Checklist before commissioning	14
For the user	15
9 User safety instructions	15
9.1 Instructions for safe operation	15
10 About the system	15
11 Before operation	15
12 Operation	16
12.1 Operation range.....	16
13 Energy saving and optimum operation	16
14 Maintenance and service	16
14.1 Maintenance safety precautions.....	16
14.2 Precautions for maintenance and service	16
14.3 Cleaning the air filter, suction grille, air outlet and outside panels.....	17
14.3.1 To clean the air filter	17
14.4 Maintenance after a long stop period	18
14.5 After-sales service and warranty	18
14.5.1 Recommended maintenance and inspection.....	18
14.5.2 Shortened maintenance and replacement cycles	18

15 Troubleshooting	18
15.1 Relocation.....	19
16 Disposal	19
17 Technical data	20
17.1 Wiring diagram	21
17.2 Dimensions.....	22
18 Information requirements for ecodesign	24

1 About the documentation

1.1 About this document



WARNING

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children SHALL NOT play with the appliance.

Cleaning and user maintenance SHALL NOT be made by children without supervision.

Target audience

Authorised installers + end users



INFORMATION

This appliance is intended to be used in commercial, industrial or business environment.

Documentation set

This document is part of a documentation set. The complete set consists of:

- **General safety precautions:**
 - Safety instructions that you must read before installing
 - Format: Paper (in the box of the indoor unit)
- **Indoor unit installation and operation manual:**
 - Installation and operation instructions
 - Format: Paper (in the box of the indoor unit)
 - Format: Digital files on <https://www.daikin.eu>. Use the search function 🔍 to find your model.

The latest revision of the supplied documentation is published on the regional Daikin website and is available via your dealer.

The original instructions are written in English. All other languages are translations of the original instructions.

Technical engineering data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of the latest technical data is available on the Daikin Business Portal (authentication required).

1.2 Meaning of warnings and symbols



DANGER

Indicates a situation that results in death or serious injury.



DANGER: RISK OF ELECTROCUTION

Indicates a situation that could result in electrocution.



DANGER: RISK OF BURNING/SCALDING

Indicates a situation that could result in burning/scalding because of extreme hot or cold temperatures.

2 Specific installer safety instructions



WARNING

Indicates a situation that could result in death or serious injury.



CAUTION

Indicates a situation that could result in minor or moderate injury.



NOTICE

Indicates a situation that could result in equipment or property damage.



INFORMATION

Indicates useful tips or additional information.

Symbols used on the unit:

Symbol	Explanation
	Before installation, read the installation and operation manual, and the wiring instruction sheet.

1.3 General

If you are NOT sure how to install or operate the unit, contact your dealer.



WARNING

Improper installation or attachment of equipment or accessories could result in electrical shock, short-circuit, leaks, fire or other damage to the equipment. **ONLY** use accessories, optional equipment and spare parts made or approved by Daikin unless otherwise specified.



WARNING

Make sure installation, testing and applied materials comply with applicable legislation (on top of the instructions described in the Daikin documentation).



CAUTION

Wear adequate personal protective equipment (protective gloves, safety glasses,...) when installing, maintaining or servicing the system.



WARNING

Tear apart and throw away plastic packaging bags so that nobody, especially children, can play with them. **Possible consequence:** suffocation.



WARNING

Provide adequate measures to prevent that the unit can be used as a shelter by small animals. Small animals that make contact with electrical parts can cause malfunctions, smoke or fire.



CAUTION

Do NOT touch the air inlet or aluminium fins of the unit.



CAUTION

- Do NOT place any objects or equipment on top of the unit.
- Do NOT sit, climb or stand on the unit.



DANGER: RISK OF ELECTROCUTION

- Make sure that the system is earthed properly.
- Turn OFF the power supply before servicing.
- Install the switch box cover before turning ON the power supply.



CAUTION

- Check if the installation location can support the unit's weight. Poor installation is hazardous. It can also cause vibrations or unusual operating noise.
- Provide sufficient service space.
- Do NOT install the unit so that it is in contact with a ceiling or a wall, as this may cause vibrations.



DANGER: RISK OF ELECTROCUTION

Do NOT operate the fan coil units with wet hands. An electrical shock may result.



WARNING

This unit contains electrical and hot parts.

2 Specific installer safety instructions

Always observe the following safety instructions and regulations.



WARNING

Make sure installation, servicing, maintenance and repair comply with instructions from Daikin and with applicable legislation (for example national gas regulation) and are executed **ONLY** by authorised persons.



WARNING

Keep the interconnection wiring away from copper pipes without thermal insulation as such pipes will be very hot.



CAUTION

For walls containing a metal frame or a metal board, use a wall embedded pipe and wall cover in the feed-through hole to prevent possible heat, electrical shock, or fire.



NOTICE

- The pipework shall be securely mounted and guarded protected from physical damage.
- Keep the pipework installation to a minimum.



WARNING

- Do NOT use locally purchased electrical parts inside the product.
- Do NOT branch the power supply for the valve etc. from terminal block. This could result in electrical shock or fire.



WARNING

Installation shall be done by an installer, the choice of materials and installation shall comply with the applicable legislation.

For the installer

3 About the box


Keep the following in mind:

- At delivery, the unit **MUST** be checked for damage and completeness. Any damage or missing parts **MUST** be reported immediately to the claims agent of the carrier.
- Bring the packed unit as close as possible to its final installation position to prevent damage during transport.
- Prepare in advance the path along which you want to bring the unit to its final installation position.

3.1 To unpack and handle the fan coil unit


Use a sling of soft material or protective plates together with a rope when lifting the unit. This to avoid damage or scratches to the unit.

- Lift the unit by holding onto the hanger brackets without exerting any pressure on other parts, especially on drain piping and thermal insulation.




! NOTICE

Do NOT lift the unit by the valve actuators (a).




! NOTICE

Do NOT lift the unit by the drain pan socket (b).




! NOTICE

Do NOT lift the unit by subdrain pan (c).



3.2 To remove the accessories from the fan coil unit



- a Metal clamp
- b Drain hose
- c Washer for hanger bracket
- d Screw
- e Gasket
- f Large sealing pad for drain hose
- g Installation and operation manual
- h Anti-sweat cover
- i Installation guide
- j Protective tube (Heat shrinkable tube)
- k Thermal insulation for valves (2 pipe: 1x and 4 pipe: 2x) (*)
- l Tie wrap for valve thermal insulation (2 pipe: 2x and 4 pipe: 4x) (*)
- m Tie wrap for fixing field cable as a spare part x2
- n Tie wrap (Heat resisting) x4
- o Sub drain pan
- * Only models with factory mounted valve


4 About the units and options

4 About the units and options

4.1 Identification

4.1.1 Identification label: Fan coil unit

Location



Model identification

Example: F W Q 04 A A T N 5 V1--

Code	Description
F	Fan coil unit
W	Water
Q	Duct (Medium ESP) BLDC motor
04	Nominal total capacity (kW) (04=2 kW)
A	Major model series
A	Minor model change
T	2 pipe
F	4 pipe
N	Without valve
V	3-way valve (ON/OFF - 230 V)
T	2-way valve (ON/OFF - 230 V)
5	Hendek factory
V1	1 Phase / 220-240 V/ 50 Hz
-	No options
-	"-" , Left side water, Right side electric connection "R", Right side water – Left side electric connection

5 Unit installation

5.1 Preparing the installation site



WARNING

ALWAYS use non-flammable ducts, thermal insulations and couplings; flammable materials may cause a fire.




NOTICE

The unit must be installed ≥ 2.5 m from the floor.



NOTICE

The spacing between ceiling and unit should be ≥ 10 mm and the suction space should be ≥ 150 mm.



INFORMATION

The sound pressure level is less than 70 dBA.



CAUTION

Appliance is NOT accessible to the general public. Install it in a secured area, protected from easy access.

This unit is suitable for installation in a commercial and light industrial environment.



NOTICE

Where installation from below is NOT possible, such as very high ceilings, access to the unit for installation and service should be possible from the top of the ceiling.

Select an installation site that fulfills the following conditions and meets with your customer's approval.

- The space around the unit is adequate for maintenance and servicing. The space around the unit allows sufficient air circulation and air distribution. See space required for installation.
- Make sure the area is well ventilated. Do NOT block any ventilation openings.
- Make sure the installation site withstands the weight and vibration of the unit.
- Ensure that in the event of a water leak, no damage occurs to the installation space or its surroundings.
- Choose a location where the operation noise or the hot/cold air discharged from the unit will not disturb anyone and the location is selected according the applicable legislation.
- **Drainage.** Make sure condensation water can be evacuated properly.
- In places with weak reception, keep distances of 3 m or more to avoid electromagnetic disturbance of other equipment and use conduit tubes for power and transmission lines.
- **Fluorescent lights.** When installing a wireless remote control (user interface) in a room with fluorescent lights, mind the following to avoid interference:
 - Install the wireless remote control (user interface) as close as possible to the indoor unit.
 - Install the indoor unit as far as possible from the fluorescent lights.

Do NOT install the unit in places often used as work place. In case of construction works (e.g. grinding works) where a lot of dust is created, the unit MUST be covered.

Do not install or operate the unit in rooms mentioned below.


- Places with mineral oil, or filled with oil vapour or spray, like in kitchens (plastic parts may deteriorate).
- Where corrosive gas like sulphurous gas exists. Copper tubing and brazed spots may corrode.
- Where the air contains high levels of salt, such as that near the coast and where voltage fluctuates a lot (e.g. in factories). Also in vehicles or vessels.

- In places where there is machinery that emits electromagnetic waves. Electromagnetic waves may disturb the control system, and cause malfunction of the equipment.
- In places where there is a risk of fire due to the leakage of flammable gases (example: thinner or gasoline), carbon fibre, ignitable dust.
- The unit can NOT be installed in a bathroom.


5.2 Interchangeability

The direction of the product must be changed on the ground.


- 1 Remove the cover sheet metal, hold plate, and drain pans from the unit.




- 2 Unscrew the heat exchanger fixing screws and remove the heat exchanger from the unit.



- 3 Remove the support plates from the heat exchanger.




- 4 Turn the heat exchanger in the direction indicated below.





- 5 Mount the support plates onto the heat exchanger in the correct position shown below.

5 Unit installation




6 Mount the plastic components, metal sheet, and drain pans as illustrated below.



5.3 Mounting the unit

5.3.1 To install the suspension bolts

Use the pattern to determine the suspension bolt positions (upper part of the packing). Suspension bolt positions are indicated on the paper pattern. Holes can be drilled by putting the paper pattern on the ceiling.




a Paper pattern for installation. (upper part of the packing)


5.3.2 To mount the unit

Make the required ceiling opening for installation in an applicable place. It may be necessary to reinforce the suspended ceiling frame to keep the ceiling level and to prevent it from vibrating.

Consult the builder for details.



- **Ceiling strength.** Check whether the ceiling is strong enough to support the weight of the unit. If there is a risk, reinforce the ceiling before installing the unit.
 - For existing ceilings, use anchors.
 - For new ceilings, use sunken inserts, sunken anchors or other field supplied parts.




NOTICE

Always use upper air purges.

- a Ceiling slab
- b Anchor
- c Long nut or turn-buckle
- d Suspension bolt


- **Suspension bolts.** Use M8~M10 suspension bolts for installation. Attach the hanger bracket to the suspension bolt. Fix it securely using a nut and washer from the upper and lower sides of the hanger bracket.




- a Nut (field supply)
- b Washer (field supply)
- c Hanger bracket
- d Double nut (field supply)

- Adjust the unit to the correct position for installation.


For left models:



For right models:



- Check if the unit is horizontally levelled.
- **Level.** Make sure the unit is level at all 4 corners using a level or a water-filled vinyl tube.



- a Level
- b Vinyl tube



NOTICE

Do NOT install the unit tilted. **Possible consequence:** If the unit is tilted against the direction of the condensate flow (the drain piping side is raised), water may drip.

5.4 Water piping installation

5.4.1 Preparing water piping

Before performing the water piping work, check the following points:

- The maximum water pressure is 1.6 MPa.
- The unit is equipped with a water inlet and water outlet for connection to the water circuit. The water circuit must be provided by an installer and must comply with the applicable legislation.
- The minimum water temperature is 5°C.
- The maximum water temperature is 90°C.
- Be sure to install components in the field piping that can withstand the water pressure and temperature.
- Provide adequate safeguards in the water circuit to ensure that the water pressure will never exceed the maximum allowable working pressure.
- Provide a proper drain for the pressure relief valve (if installed) to avoid any water from coming into contact with electrical parts.
- Provide shut-off valves at the unit so that normal servicing can be accomplished without draining the system.
- Provide drain taps at all low points of the system to permit complete draining of the circuit during maintenance or service to the unit.
- Provide air purge valves at all high points of the system. The valves shall be located at points which are easily accessible for servicing.
- Pipework shall be protected from physical damage.



NOTICE

Make sure water quality complies with EU directive 2020/2184.



NOTICE

Use of glycol is allowed, but the amount shall NOT exceed 40% of the volume. A higher amount of glycol may cause damage to the hydraulic components.

5 Unit installation



NOTICE

The unit is **ONLY** to be used in a closed water system. Application in an open water circuit can lead to excessive corrosion of the water piping.

5.4.2 Connecting water piping



CAUTION

Always use valves to control water circulation in the unit. If the fan coil unit is off, but water keeps circulating in the unit, condensation will form on the unit and water may drip.



NOTICE

Do not use excessive force when connecting the piping. This could deform the unit piping. Deformation of the piping can cause the unit to malfunction.




NOTICE

Make sure to insulate all piping. Any exposed piping might cause condensation.



DANGER: RISK OF BURNING/SCALDING




NOTICE

The water piping installation representations under the title 'Connecting water piping' are shown based on the viewpoint presented in the illustration above.


FWQ(04/05/07/09/11/14/17/20/25)AA(T/F)(N/T/V)5V1--

FWQ(04/05/07/09/11/14/17/20/25)AA(T/F)(N/T/V)5V1-R



- a Hot water outlet (3/4 female BSP)
- b Hot water inlet (3/4 female BSP)
- c Heating air purge
- d Cooling outlet (3/4 female BSP)
- e Cooling air purge
- f Cooling inlet (3/4 female BSP)

To fill the water circuit



- a Air purge
- b Pressure relief valve
- c Cap

During filling, it might not be possible to remove all air in the system. Remaining air can be removed during the first operating hours of the unit. The air can be removed from the unit through the manual air purge valve.

- 1 Open the cap.
- 2 Push the pressure relief valve to purge air from the unit water circuit(s).
- 3 Close the cap.
- 4 Additional filling with water afterwards might be required (but never through the air purge valve).



NOTICE

Air in the water circuit can cause malfunctioning. During filling, it may not be possible to remove all the air from the circuit. Remaining air will be removed through the automatic air purge valves during the initial operating hours of the system. Additional filling with water afterwards may be required.



NOTICE


Make sure water quality complies with EU directive 2020/2184.

5.5 Drain piping installation

5.5.1 Guidelines when installing the drain piping


General guidelines

- **Pipe length.** Keep drain piping as short as possible.
- **Pipe size.** Keep the pipe size equal to or greater than that of the connecting pipe (vinyl pipe of 25 mm nominal diameter and 32 mm outer diameter).
- **Slope.** Make sure the drain piping slopes down (at least 1/100) to prevent air from being trapped in the piping. Use hanging bars as shown.
- **Condensation.** Take measures against condensation. Insulate the complete drain piping in the building.
- **Slope.** Make sure the drain piping slopes down (at least 1/50) to prevent air from being trapped in the piping. Use hanging bars as shown.



- ✓ a Hanging bar
 Allowed
✗ Not allowed

- If necessary to make the slope possible, you can install rising piping.
 - Drain hose inclination: 0~75 mm to avoid stress on the piping and to avoid air bubbles.
 - Rising piping: ≤300 mm from the unit, ≤675 mm perpendicular to the unit.



- a Metal clamp (accessory)
 b Drain hose (accessory)
 c Rising drain piping (vinyl pipe of 25 mm nominal diameter and 32 mm outer diameter) (field supply)
 d Hanging bars (field supply)

5.5.2 Connecting the drain piping

To connect the drain piping



NOTICE


Incorrect connection of the drain hose might cause leaks, and damage the installation space and surroundings.

- Push the drain hose as far as possible over the drain socket.
- Tighten the screw from drain hose to drain pan's surface.
- Check for water leaks.




NOTICE

Since the unit is equipped with a drain pump, some water may remain in the drain pan. To discharge it, remove the rubber plug (b), then reinstall it firmly after draining.



- a Drain socket
 b Rubber plug

- Insert the drain hose and tighten with fixing screw (accessory set).



- c Drain hose



NOTICE

The unit must be used with a drain hose. (Forgetting to tighten this may cause water leakages and vibrations.)

5.6 Optional equipment installation

5.6.1 Preparing of optional equipment



INFORMATION

Optional equipment. When installing optional equipment, also read the installation manual of the optional equipment. Depending on the field conditions, it might be easier to install the optional equipment first.

Optional equipment	Identification code
2-way valve- ON/OFF (AC 230 V)	EK02WV2V3W5A
2-way valve- ON/OFF (AC 230 V)	EK08WV2V3D5A
2-way valve- ON/OFF (AC 230 V)	EK06WV2V3C5A
3-way valve- ON/OFF (AC 230 V)	EK02WV3V3W5A
3-way valve- ON/OFF (AC 230 V)	EK08WV3V3D5A
3-way valve- ON/OFF (AC 230 V)	EK06WV3V3C5A
PICV FAN-Q DN20 HF	E4C2QPICV20D5A
PICV AB-QM 4.0 15 HF	E4C2APICV15D5A
PICV AB-QM 4.0 20 HF	E4C2APICV20D5A
G3 filter media (600mm)	EKAF06G3PQ5A
G3 filter media (800mm)	EKAF08G3PQ5A
G3 filter media (1100mm)	EKAF11G3PQ5A
G3 filter media (1500mm)	EKAF15G3PQ5A
G4 filter media (600mm)	EKAF06G4PQ5A
G4 filter media (800mm)	EKAF08G4PQ5A
G4 filter media (1100mm)	EKAF11G4PQ5A

6 Electrical installation

Optional equipment	Identification code
G4 filter media (1500mm)	EKAF15G4PQ5A
Plenum for discharge side (for FWQ(04/05)AA)	EKPLEN1Q5A
Plenum for discharge side (for FWQ(07)AA)	EKPLEN2Q5A
Plenum for discharge side (for FWQ(09/11/14)AA)	EKPLEN3Q5A
Plenum for discharge side (for FWQ(17/20/25)AA)	EKPLEN4Q5A

6 Electrical installation



DANGER: RISK OF ELECTROCUTION



WARNING

ALWAYS use multicore cable for power supply cables.



WARNING

Use an all-pole disconnection type breaker with at least 3 mm between the contact point gaps that provides full disconnection under overvoltage category III.

6.1 Preparing electrical wiring



WARNING

All field wiring and components **MUST** be installed by a licensed electrician and **MUST** comply with the applicable legislation.



DANGER: RISK OF ELECTROCUTION



WARNING

A main switch or other means for disconnection, having a contact separation in all poles, **MUST** be incorporated in the fixed wiring in accordance with the applicable legislation.



CAUTION

- When connecting the power supply: connect the earth cable first, before making the current-carrying connections.
- When disconnecting the power supply: disconnect the current-carrying cables first, before separating the earth connection.
- The length of the conductors between the power supply stress relief and the terminal block itself **MUST** be as such that the current-carrying wires are tightened before the earth wire is in case the power supply is pulled loose from the stress relief.



WARNING

- After finishing the electrical work, confirm that each electrical component and terminal inside the switch box is connected securely.
- Make sure all covers are closed before starting up the unit.



WARNING

Do **NOT** apply any permanent inductive or capacitance loads to the circuit without ensuring that this will **NOT** exceed the permissible voltage and current permitted for the equipment in use.



NOTICE

The equipment described in this manual may cause electronic noise generated from radio-frequency energy. The equipment complies with specifications that are designed to provide reasonable protection against such interference. However, there is no guarantee that interference will not occur in a particular installation.

It is therefore recommended to install the equipment and electric wires in such a way that they keep a proper distance from stereo equipment, personal computers, etc.



DANGER: RISK OF ELECTROCUTION

- Turn OFF all power supply before removing the fan coil unit terminal cover when connecting electrical wiring or touching electrical parts.
- Disconnect the power supply for more than 10 minutes, and measure the voltage at the terminals of main circuit capacitors or electrical components before servicing. The voltage **MUST** be less than 50 V DC before you can touch electrical components. For the location of the terminals, see the wiring diagram.
- Do **NOT** touch electrical components with wet hands.
- Do **NOT** leave the unit unattended when the terminal cover is removed.



WARNING

- ONLY** use copper wires.
- Make sure the field wiring complies with the applicable legislation.
- All field wiring **MUST** be performed in accordance with the wiring diagram supplied with the product.
- NEVER** squeeze bundled cables and make sure they do **NOT** come into contact with the piping and sharp edges. Make sure no external pressure is applied to the terminal connections.
- Make sure to install earth wiring. Do **NOT** earth the unit to a utility pipe, surge absorber, or telephone earth. Incomplete earthing may cause electrical shock.
- Make sure to install the required fuses or circuit breakers.
- Make sure to install an earth leakage protector. Failure to do so may cause electrical shock or fire.

6-1 Field wiring specifications

Specifications	
Recommended overcurrent fuse (A)	5
Phase	1
Frequency (Hz)	50
Voltage (V)	220~240
Voltage tolerance (%)	±10
Wire size (cross section mm ²)	0.75~1.25
Earth leakage circuit breaker	Must comply with applicable legislation

6.2 Connecting the electrical wiring



DANGER: RISK OF ELECTROCUTION



WARNING

ALWAYS use multicore cable for power supply cables.



WARNING

Use an all-pole disconnection type breaker with at least 3 mm between the contact point gaps that provides full disconnection under overvoltage category III.



NOTICE

Precautions when laying power wiring:



- Do NOT connect wiring of different thicknesses to the power terminal block (slack in the power wiring may cause abnormal heat).
- When connecting wiring which is the same thickness, do as shown in the figure above.
- For wiring, use the designated power wire and connect firmly, then secure to prevent outside pressure being exerted on the terminal board.
- Use an appropriate screwdriver for tightening the terminal screws. A screwdriver with a small head will damage the head and make proper tightening impossible.
- Over-tightening the terminal screws may break them.



NOTICE

- Follow the wiring diagram (delivered with the unit, located at the inside of the service cover).
- For instructions on how to connect the optional equipment, see the installation manual delivered with the optional equipment.
- Make sure the electrical wiring does NOT obstruct proper reattachment of the service cover.

It is important to keep the power supply and the interconnection wiring separated from each other. In order to avoid any electrical interference, the distance between both wirings should ALWAYS be at least 50 mm.



NOTICE


Be sure to keep the power line and interconnection line apart from each other. Interconnection wiring and power supply wiring may cross, but may NOT run parallel.

1)




CAUTION


Carefully cut the protection rubber (a) using a suitable tool to create an opening, and route the cable through it. Handle the tool safely to avoid injury.



2) First, pass the 0-10 V DC fan modulation cable through the protection rubber (a), and connect it to the X2M terminal. Use the cable clamps (b) to secure the cable.




3) Pass the AC heating and cooling signal cables through the protection rubber (a), and connect them from the remote controller to the X2M terminal. Use the cable clamps (c) to secure the cables.




4) Connect the L, N, and Earth wires for the power supply of the remote controller to the lower part of the X1M terminal.


7 Configuration



5) Connect the power supply cables (L, N, Earth) to the upper part of the X1M terminal.




6) Close the electrical box cover after completing the electrical connections.



7 Configuration

7.1 DIP switch positioning

M speed at 50 Pa Eurovent standard condition is declared. If ESP at M speed is higher than 50 Pa, you can prevent a decrease in capacity due to high ESP by changing the Dip Switch setting. For details on DIP SW settings and performance specifications, refer to FSS.



(*) M speed 50Pa Eurovent rated condition (factory setting).

8 Commissioning



NOTICE

Do NOT interrupt the test run.

8.1 Checklist before commissioning

- 1 After the installation of the unit, check the items listed below.
- 2 Close the unit.
- 3 Power up the unit.

<input type="checkbox"/>	You read the complete installation instructions, as described in the installer reference guide .
<input type="checkbox"/>	The indoor units are properly mounted.
<input type="checkbox"/>	There are NO missing phases or reversed phases .
<input type="checkbox"/>	The system is properly earthed and the earth terminals are tightened.
<input type="checkbox"/>	The fuses or locally installed protection devices are installed according to this document, and have NOT been bypassed.
<input type="checkbox"/>	The power supply voltage matches the voltage on the identification label of the unit.
<input type="checkbox"/>	There are NO loose connections or damaged electrical components in the switch box.
<input type="checkbox"/>	There are NO damaged components or squeezed pipes on the inside of the indoor and outdoor units.
<input type="checkbox"/>	The correct pipe size is installed and the pipes are properly insulated.

For the user

9 User safety instructions

Always observe the following safety instructions and regulations.

9.1 Instructions for safe operation

**CAUTION**

Do NOT insert fingers, rods or other objects into the air inlet or outlet. When the fan is rotating at high speed, it will cause injury.

**CAUTION: Pay attention to the fan!**

It is dangerous to inspect the unit while the fan is running.

Make sure to turn OFF the main switch before executing any maintenance task.

**CAUTION**

After a long use, check the unit stand and fitting for damage. If damaged, the unit may fall and result in injury.

**CAUTION**

It is unhealthy to expose your body to the air flow for a long time.

**CAUTION**

NEVER touch the internal parts of the controller.

**DANGER: RISK OF ELECTROCUTION**

To clean the air filter, be sure to stop operation and turn all power supplies OFF. Otherwise, an electrical shock and injury may result.

**WARNING**

Keep any required ventilation openings clear of obstructions.

**WARNING**

Do NOT place a flammable spray bottle near the air conditioner and do NOT use sprays near the unit. Doing so may result in a fire.

**WARNING**

Before operating the unit, be sure the installation has been carried out correctly by an installer.

**WARNING**

The appliance shall be stored so as to prevent mechanical damage and in a well-ventilated room without continuously operating ignition sources (e.g. open flames, an operating gas appliance, or an operating electric heater). The room size shall be as specified in the General safety precaution.

**WARNING**

Stop operation and shut OFF the power if anything unusual occurs (burning smells etc.).

Leaving the unit running under such circumstances may cause breakage, electrical shock or fire. Contact your dealer.

10 About the system

**WARNING**

Do NOT modify, disassemble, remove, reinstall or repair the unit yourself as incorrect dismantling or installation may cause an electrical shock or fire. Contact your dealer.

**NOTICE**

Do NOT use the system for other purposes. In order to avoid any quality deterioration, do NOT use the unit for cooling precision instruments, food, plants, animals, or works of art.

**NOTICE**

For future modifications or expansions of your system:

A full overview of allowable combinations (for future system extensions) is available in technical engineering data and should be consulted. Contact your installer to receive more information and professional advice.

11 Before operation

**WARNING**

This unit contains electrical and hot parts.

**WARNING**

Before operating the unit, be sure the installation has been carried out correctly by an installer.

**CAUTION**

NEVER expose little children, plants or animals directly to the airflow.

This operation manual is for the following systems with standard control. Before initiating operation, contact your dealer for the operation that corresponds to your system type and mark. If your installation has a customised control system, ask your dealer for the operation that corresponds to your system.

Operation modes:

- Heating and cooling (air to air).
- Fan only operation (air to air).

12 Operation

This operation manual offers a non-exhaustive overview of the main functions of the system.

For more information about the user interface, see the operation manual of the installed user interface.

12 Operation

12.1 Operation range

The following conditions are standard operating limits. For different conditions, please consult the dealer.

Operation mode	Operation range
Cooling ^{(a)(b)}	<ul style="list-style-type: none">Air temperature limit: DB: 15°C~33°C – WB: 11.6°C~29°CWater temperature limit (in/out): 5°C/28°CWater delta T, ΔT: 3~10
Heating	<ul style="list-style-type: none">Air temperature limit: DB: 15°C~27°CWater temperature limit: 35°C~90°CWater delta T, ΔT: 5~20

^(a) The limit of room air relative humidity is RH≤80%.

^(b) Condensation and water dripping might occur if the unit runs outside its operation range.

13 Energy saving and optimum operation

Observe the following precautions to ensure the system operates properly.

- Adjust the air outlet properly and avoid direct air flow to room inhabitants.
- Adjust the room temperature properly for a comfortable environment. Avoid excessive heating or cooling.
- Prevent direct sunlight from entering a room during cooling operation by using curtains or blinds.
- Ventilate often. Extended use requires special attention to ventilation.
- Keep doors and windows closed. If the doors and windows remain open, air will flow out of your room causing a decrease in the cooling or heating effect.
- Be careful NOT to cool or heat too much. To save energy, keep the temperature setting at a moderate level.
- NEVER place objects near the air inlet or the air outlet of the unit. Doing so may cause a reduced heating/cooling effect or stop operation.



NOTICE

Do NOT use the system for other purposes. In order to avoid any quality deterioration, do NOT use the unit for cooling precision instruments, food, plants, animals, or works of art.



CAUTION

Do NOT operate the system when using a room fumigation-type insecticide. Chemicals could collect in the unit, and endanger the health of people who are hypersensitive to chemicals.

14 Maintenance and service

14.1 Maintenance safety precautions



DANGER: RISK OF BURNING/SCALDING



DANGER: RISK OF ELECTROCUTION



NOTICE

Keep the air filter clean and check the airflow rate periodically.



WARNING

- Before carrying out any maintenance or repair activity, ALWAYS switch off the circuit breaker on the supply panel.
- Make sure you do NOT touch a conductive section.
- Do NOT rinse the outside of the unit. This may cause electric shocks or fire.

To clean the outside of your fan coil unit:

- Switch off the fan coil unit.
- Clean the outside of the fan coil unit with a soft cloth.



CAUTION

- Do NOT obstruct the air outlet or inlet of the unit in any way.
- Do NOT place damp or wet clothing on the air outlet grille of the unit.
- Do NOT pour liquids inside the equipment.

Never clean your fan coil unit with:

- any aggressive chemical solvent,
- water hotter than 50°C.

For maintenance of your fan coil unit, contact your installer or service company.

14.2 Precautions for maintenance and service



WARNING

NEVER replace a fuse with a fuse of a wrong ampere ratings or other wires when a fuse blows out. Use of wire or copper wire may cause the unit to break down or cause a fire.



CAUTION

After a long use, check the unit stand and fitting for damage. If damaged, the unit may fall and result in injury.



CAUTION

Before accessing terminal devices, make sure to interrupt all power supply.



NOTICE

When cleaning the heat exchanger, make sure to remove the switch box, fan motor, drain pump and float switch. Water or detergent might deteriorate the insulation of electronic components and result in burnout of these components.



WARNING

Be careful with ladders when working in high places.

**NOTICE**

NEVER inspect or service the unit by yourself. Ask a qualified service person to perform this work. However, as end user, you may clean the air filter.

14.3 Cleaning the air filter, suction grille, air outlet and outside panels

**CAUTION**

Turn off the unit before cleaning the air filter, suction grille, air outlet and outside panels.

**NOTICE**

- Do NOT scrub firmly when washing the blade with water. **Possible consequence:** The surface sealing peels off.

Clean with a soft cloth. If it is difficult to remove stains, use water or a neutral detergent.

14.3.1 To clean the air filter




When to clean the air filter:

- Rule of thumb: Clean every 6 months. If the air in the room is extremely contaminated, increase the cleaning frequency.
- If the dirt becomes impossible to clean, change the air filter (= optional equipment).


How to clean the air filter:
**NOTICE**

Do NOT use water of 50°C or higher. **Possible consequence:** Discoloration and deformation.


- Switch off the power supply. The air filter can be installed on both the right side and left sides. Remove the filter by sliding, as shown below.



- Separate the filters from each other.




- Clean the air filter. Use a vacuum cleaner or wash with water. If the air filter is very dirty, use a soft brush and neutral detergent.



15 Troubleshooting

- 4 Dry the air filter in the shade.
- 5 Reattach the air filter and close the suction grille.



14.4 Maintenance after a long stop period

E.g., at the beginning of the season.

- Check and remove everything that might be blocking inlet and outlet vents of indoor units and outdoor units.
- Clean air filters and casings of indoor units (see ["14.3.1 To clean the air filter"](#) ▶ 17) and To clean the air outlet and outside panels).

14.5 After-sales service and warranty

14.5.1 Recommended maintenance and inspection

Since dust collects when using the unit for several years, performance of the unit will deteriorate to some extent. As taking apart and cleaning interiors of units requires technical expertise and in order to ensure the best possible maintenance of your units, we recommend to enter into a maintenance and inspection contract on top of normal maintenance activities. Our network of dealers has access to a permanent stock of essential components in order to keep your unit in operation as long as possible. Contact your dealer for more information.

When asking your dealer for an intervention, always state:

- The complete model name of the unit.
- The manufacturing number (stated on the nameplate of the unit).
- The installation date.
- The symptoms or malfunction, and details of the defect.



WARNING

Do NOT modify, disassemble, remove, reinstall or repair the unit yourself as incorrect dismantling or installation may cause an electrical shock or fire. Contact your dealer.

14.5.2 Shortened maintenance and replacement cycles

Shortening of "maintenance cycle" and "replacement cycle" needs to be considered in following situations:

The unit is used in locations where:

- Heat and humidity fluctuate out of the ordinary.

- Power fluctuation is high (voltage, frequency, wave distortion, etc.) (the unit cannot be used if power fluctuation is outside the allowable range).
- Bumps and vibrations are frequent.
- Dust, salt, harmful gas or oil mist such as sulphurous acid and hydrogen sulfide may be present in the air.
- The machine is started and stopped frequently or operation time is long (sites with 24 hour air-conditioning).

Recommended replacement cycle of wear parts

Component	Inspection cycle	Maintenance cycle (replacements and/or repairs)
Air filter	6 months	5 years
Fuse	1 year	10 years



INFORMATION

Damage due to taking apart or cleaning interiors of units by anyone other than our authorised dealers may not be included in the warranty.

15 Troubleshooting

If one of the following malfunctions occurs, take the measures shown below and contact your dealer.

The system **MUST** be repaired by a qualified service person.

Malfunction	Measure
If a safety device such as a fuse, a breaker or an earth leakage breaker frequently actuates or the ON/OFF switch does not properly work.	Turn off the main power switch.
If water leaks from the unit.	Stop the operation.
The operation switch does not work well.	Turn off the power.

If the system does NOT operate properly except for the above mentioned cases and none of the above mentioned malfunctions is evident, investigate the system in accordance with the following procedures.

Malfunction	Measure
If the system does not operate at all.	<ul style="list-style-type: none"> ▪ Check if there is no power failure. Wait until power is restored. ▪ Check if no fuse has blown or breaker is activated. Change the fuse or reset the breaker if necessary.
The system operates but cooling or heating is insufficient.	<ul style="list-style-type: none"> ▪ Check if air inlet or outlet of the fan coil unit is not blocked by obstacles. Remove any obstacles and make sure the air can flow freely. ▪ Check if the air filter is not clogged (see "14.3.1 To clean the air filter" ▶ 17). ▪ Check the temperature setting. ▪ Check the fan speed setting on your user interface. ▪ Check for open doors or windows. Close doors and windows to prevent wind from coming in. ▪ Check if there are too many occupants in the room during cooling operation. Check if the heat source of the room is excessive. ▪ Check if direct sunlight enters the room. Use curtains or blinds. ▪ Check if the air flow angle is proper.

After checking all the items above, if it is impossible to fix the problem yourself, contact your installer and state the symptoms, the complete model name of the unit (with manufacturing number if possible) and the installation date.

15.1 Relocation

Contact your dealer to remove and reinstall the entire unit. Moving units requires technical expertise.

16 Disposal

- Units are marked with the following symbol:



This means that electrical and electronic products may NOT be mixed with unsorted household waste. Do NOT try to dismantle the system yourself: dismantling the system, treatment of the refrigerant, oil and of other parts MUST be done by an authorised installer and MUST comply with applicable legislation.

Units MUST be treated at a specialised treatment facility for reuse, recycling and recovery. By ensuring this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health. For more information, contact your installer or local authority.




NOTICE


Do NOT try to dismantle the system yourself: dismantling of the system, treatment of the refrigerant, oil and other parts MUST comply with applicable legislation. Units MUST be treated at a specialised treatment facility for reuse, recycling and recovery.

After installation, the installer is obliged to verify correct operation. In case something is wrong with the unit and it does not operate, contact your local dealer.

Use the proper tool to remove the screws. The product can be disassembled as shown below.



17 Technical data




Materials	Item
Electrical part	24, 40, 41, 61, 63, 64
Aluminium (fin) + copper (tube) + galvanised steel (plate) + brass	3
Plastic	6, 12, 13, 16, 25, 26, 37, 55, 56, 58, 59, 66
Plastic foam	4, 5, 6, 9, 19, 28
Plastic + metal	65
Plastic (frame) + plastic (net)	54
Galvasined steel	2, 7, 8, 17, 20, 22, 30, 36, 38, 42, 44, 45, 46, 48, 49, 51, 52, 53, 57, 62
Galvasined steel + plastic foam	1, 10, 14, 18, 29, 31, 32, 33, 50
Rubber	15, 21, 25, 27, 34, 43

17 Technical data

A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible). The **full set** of the latest technical data is available on the Daikin Business Portal (authentication required).

17.1 Wiring diagram



Colours:

BLK	Black
BLU	Blue
BRN	Brown
GRN	Green
PPL	Purple
ORG	Orange
RED	Red
WHT	White
YLW	Yellow

Notes:

- 1 --- : 2 PIPE, 4 PIPE **||||** : 4 PIPE ONLY
- 2 **□** : TERMINAL BLOCK **□□** : CONNECTOR **□□** : POWER SUPPLY
- 3 REFER TO INSTALLATION MANUAL FOR POWER REQUIREMENT.
- 4 PLEASE FOLLOW THE MANUAL OF THE EXTERNAL REMOTE CONTROLLER FOR THE WIRING DIAGRAM OF THE REMOTE CONTROLLER.
- 5 X32A AND X37A CAN ONLY BE CONNECTED TO THE SPECIFIED DAIKIN VALVE OPTIONS
- 6 EKER*** A KIT SHOULD BE USED WHEN A VALVE OUTSIDE THE OPTION LIST IS USED.

Legend for wiring diagrams:

Indoor unit:

A1P	MAIN PCB
A2P	ELECTRONIC BOARD (FWEC3AP)
A3P	ELECTRONIC CONTROL (FWEC3AC)
A4P	ADVANCED PLUS REMOTE CONTROLLER (FWEC3A)
A5P	ADAPTOR PCB (PANEL CONNECTION)
A6P	REACTOR PCB (INSIDE OF EL. COMPO. ASSY)
A7P	REMOTE CONTROLLER (FWEC10)
C305	CAPACITOR
FG	FRAME GROUND
F1U	FUSE (6.3A, 250V)
F2U	FIELD FUSE
DS1	DIP SWITCH ON PCB
H1P	FLASHING LAMP
L1	CM CHOKE (COOL)
L2	INDUCTOR
M1P	MOTOR (DRAIN PUMP)

17 Technical data

M1S	SWING MOTOR
M2S	
M3S	
M4S	
M5S	
M1F	MOTOR (DC FAN)
S1L	FLOAT SWITCH
V1R	DIODE BRIDGE
Q1R	EARTH LEAKAGE BREAKER
X1M	TERMINAL STRIP (POWER SUPPLY)
X2M	TERMINAL STRIP (R/C SIGNAL AND VALVE TERMINAL & FAN MODULATING)
Z1F	NOISE FILTER
Z1C	FERRITE CORE
Z2C	FERRITE CORE
PS	SWITCHING POWER SUPPLY
M1B	HEATING ACTUATOR (4 PIPE ONLY)
M2B	COOLING ACTUATOR

PCB connections:

X6A	REACTOR
X15A	FLOAT SWITCH
X20A	BLDC MOTOR
X24A	FAN MODULATING
X25A	DRAIN PUMP
X27A	POWER SUPPLY
X32A	COOLING VALVE
X33A	R/C SIGNAL AND VALVE
X35A	ELECTRICAL HEATER
X36A	STEPPING MOTOR (DEC.PANEL)
X37A	HEATING VALVE
X50A	SERIAL COMMUNICATION

Terminal connections:

0-10 V	0-10 V DC FAN MODULATING
COM	COMMON
HEAT	HEATING SIGNAL
COOL	COOLING SIGNAL

Electronic board (FWEDA)

C56	DO5 /DO6 COMMON
DO5	COOLING VALVE
DO6	HEATING VALVE
AC OUT1	24 Vac LINE
AC OUT2	24 Vac LINE
L	PHASE
N	NEUTRAL
PE	GROUND
+	MODBUS POSITIVE
-	MODBUS NEGATIVE
REF	REFERENCE
AO1	FAN MODULATION (0-10V)
GND	AO1 /AO2 COMMON

Display (SHINKATOUCHWA) or (SHINKATOUCHBA)


A	POSITIVE
B	NEGATIVE
GND	GROUNDING (REFERENCE)
24VAC_A	24 Vac LINE
24VAC_B	24 Vac LINE

Connector for optional parts:


T2	CONNECTOR (WIRING VALVE WIRES)
T3	CONNECTOR (POWER SUPPLY FOR DISPLAY)
T4	CONNECTOR (POWER SUPPLY FOR MODBUS)
T6	CONNECTOR (FAN MODULATING WIRES)
T9	CONNECTOR (MODBUS)
X5A	CONNECTOR (FAN MODULATING WIRES)
X7A	CONNECTOR (WIRING VALVE WIRES)
X8A	CONNECTOR (POWER SUPPLY FOR DISPLAY)

17.2 Dimensions


Overview



Model	AA	AB	AC	AD
FWQ04AA , FWQ05AA	550	629	592	769
FWQ07AA	700	779	742	919
FWQ09AA , FWQ11AA , FWQ14AA	1060	1139	1102	1279
FWQ17AA , FWQ20AA , FWQ25AA	1480	1559	1522	1699



Model	AF (mm)
FWQ(04/05/07/09/11/14)AA	50
FWQ(17/20/25)AA	44




18 Information requirements for ecodesign

Prated,c	Prated,h	Pelec	LWA
GB Cooling capacity (sensible)	GB Heating capacity	GB Total electric power input	GB Sound power level (per speed setting, if applicable)
D Kühlleistung (sensibel)	D Heizleistung	D Elektrische Gesamtleistungsaufnahme	D Schalleistungspegel (je Geschwindigkeitseinstellung, falls zutreffend)
F Puissance de rafraîchissement (sensible)	F Puissance de chauffage	F Entrée électrique totale	F Niveau de puissance sonore (par réglage de vitesse, le cas échéant)
NL Koelcapaciteit (voelbaar)	NL Verwarmingscapaciteit	NL Totaal opgenomen vermogen	NL Geluidsvormigheidsniveau (per snelheidsinstelling, indien van toepassing)
E Capacidad de refrigeración (sensibilidad)	E Capacidad de calefacción	E Potencia eléctrica de entrada total	E Nível de potencia acústica (según ajuste de velocidad, si corresponde)
I Capacità di raffreddamento (sensibile)	I Capacità di riscaldamento	I Potenza elettrica totale assorbita	I Livello di potenza sonora (per velocità impostata, se applicabile)
GR Απόδοση ψύξης (αυθηχρή)	GR Απόδοση θέρμανσης	GR Συνολική ηλεκτρική ισχύς εσοδού	GR Σύνολο ηχητικής ισχύος (ανάλογα του τρόπου, εφόσον διατίθεται)
P Capacidade de arrefecimento (sensível)	P Capacidade de aquecimento	P Entrada de potência elétrica total	P Nível de potência acústica (por regulação de velocidade, se aplicável)
TR Soğutma kapasitesi (duyarlı)	TR Isıtma kapasitesi	TR Sekillen toplam elektrik gücü	TR Ses gücü seviyesi (mümkünse hız ayarı başına)
RUС Хладопроизводительность (явная)	RUТеплопроизводительность	RUОбщая потребляемая электрическая мощность	RUУровень звукового давления (согласно настройке скорости, если применимо)
S Kyliningskapacitet (känslig)	S VärmeKapacitet	S Total effektgång	S Ljudeffektsnivå (per hastighetsinställning, om tillämpligt)
N Avkjølingskapasitet (følbart)	N Oppvarmingskapasitet	N Total effektgång	N Nivå på lydeffekt (per hastighetsinnstilling, hvis tilgjengelig)
CZ Chladicí výkon (citelný)	CZ Topný výkon	CZ Total elektrický straveffekt	CZ Hladina akustického výkonu (dle nastavení otáček pokud je to použitelné)
HR Kapacitet hlađenja (osjetljivo)	HR Kapacitet grijanja	CZ Celkový elektrický příkon	HR Razina jačine zvuka (postavka prema brzini, ako je primjenljivo)
H Hűtési teljesítmény (érzékeny)	H Fűtési teljesítmény	HR Ukupna primljena snaga električne energije	HR Hangerőszint (sebességszintenként, ha alkalmazható)
RO Capacitate de răcire (fără dezumidificare)	RO Capacitate de încălzire	RO Tejles áramforrás-bemenet	RO Nivel presiune sonoră (în funcție de turată, dacă este cazul)
SLMoč hlađenja (zaznamna)	SLMoč ogrevanja	RO Consum total de putere	SLRaven zvočne moči (glede na nastavitev hitrosti, če se uporablja)
SK Kapacita chladenia (učelná)	SK Výkon ohrevu	SLSkupna vchodná elektrická moč	SKÚroveň akustického tlaku (na príslušné nastavenie rýchlosti, ak sa používa)
ESКанацйтер на охладжәне (практически)	ESОтоплительная мощность	SKCelkový elektrický příkon	ESНиво на звуковата мощност (за различните настройки на оборотите, ако е приложимо)
PLWydajność chłodnicza (jawna)	PLWydajność grzewcza	GB Ошца входуша електрическа мощност	PLPoziom mocy dźwięku (dla ustawienia prędkości, jeśli dotyczy)
DKKoelkapacitet (mørkbart)	DKVarmekapacitet	PLCalkowita pobierana energia elektryczna	DKStejnprævniveau (efter hastighedsindstilling hvis relevant)
FINJäähdytyskapasiteetti (järkevä)	FINLämmitys steho	OKTotal elektrisk strømforsyning	FINÅnnet tehotaso (nopeusasetuksen mukaan, jos sovellettavissa)
ESTJahutusvõimsus (mõeldukas)	ESTKüttevõimsus	FINSähtevõimsus	ESTHelivõimsuse tase (võimalusel olenevalt määratud kiirusest)
LV Dzesēšanas kapacitāte (jūtama)	LV Apsildes kapacitāte	LV Kogu elektriline siensvõimsus	LV Skarņas intensitātes līmenis (attiecīgā gadījumā – katram ātruma iestatījumam)
LTVésinimo galia (tikroji)	LTVŠildymo galia	LV Kopšējā elektriskā ieejas jauda	LVGarso galios lygis (vienai greičio nuostatai, jei taikytina)
ALKapaciteti i fthjes (sensibël)	ALKapaciteti i ngrohjes	LTBendroji elektros vartojamoji galia	ALNiveli i fuqisë së tingullit (për cilësim shtepëgjësie, nëse aplikohet)
SRBKapacitet hlađenja (opipljiv)	SRBKapacitet grijanja	SRBKonsumi total i energjisë elektrike	SRBNivo zvučne snage (po podešenoj brzini, ako je primjenljivo)

	Prated,c(sen sible)	Prated,c (latent)	Prated,h	Pelec	Lwa Inlet+Rad	Lwa outlet duct	Prated,c(sen sible)	Prated,c (latent)	Prated,h	Pelec	Lwa Inlet+Rad	Lwa outlet duct
	kW	kW	kW	kW	dB	dB	kW	kW	kW	kW	dB	
FWQ04AAF	1.6	0.5	2.5	0.045	49	46	FWQ04AAT	1.8	2.8	0.045	50	47
FWQ05AAF	1.9	0.6	2.9	0.056	52	49	FWQ05AAT	2.1	3.3	0.056	53	50
FWQ07AAF	2.6	0.7	3.6	0.069	56	53	FWQ07AAT	2.9	4.0	0.069	57	54
FWQ09AAF	3.3	0.9	4.4	0.072	54	51	FWQ09AAT	3.7	4.9	0.072	55	52
FWQ11AAF	4.3	1.1	5.6	0.126	55	52	FWQ11AAT	4.7	6.5	0.126	56	53
FWQ14AAF	5.4	1.3	6.6	0.149	60	57	FWQ14AAT	5.9	7.7	0.149	61	58
FWQ17AAT	6.5	1.5	7.6	0.110	58	55	FWQ17AAT	7.1	8.8	0.110	59	56
FWQ20AAF	6.7	2.6	9.0	0.160	58	55	FWQ20AAT	7.4	10.2	0.160	59	56
FWQ25AAF	7.9	2.9	10.4	0.200	59	56	FWQ25AAT	8.6	11.08	0.200	60	57







**DAIKIN ISITMA VE SOĞUTMA SİSTEMLERİ SAN. TİC. A.Ş.**

Gölsuyu Mahallesi, Fevzi Çakmak Caddesi, Burçak Sokak, No:20, 34848 Maltepe
İSTANBUL / TÜRKİYE
Tel: 0216 453 27 00
Faks: 0216 671 06 00
Çağrı Merkezi: 444 999 0
Web: www.daikin.com.tr

Copyright 2025 Daikin

DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium

3P756931-6M 2025.10