

Field settings table

Applicable indoor units

ETSH16P30E▲▼
 ETSH16P50E▲▼
 ETSHB16P30E▲▼
 ETSHB16P50E▲▼
 ETSX16P30E▲▼
 ETSX16P50E▲▼
 ETSXB16P30E▲▼
 ETSXB16P50E▲▼

Notes

- (*1) *X*
- (*2) *H*
- (*3) *B*
- (*4) EKECBUA3V
- (*5) EKECBUA6V
- (*6) EKECBUA9W
- (*7) BUH less
- (*8) 300L tank
- (*9) E model (*E▲)
- (*10) E7 model (*E▲7)

▲ = A, B, C, ..., Z

▼ = , , 1, 2, 3, ..., 9

Field settings table				
Breadcrumb	Setting name			Range, step Default value
Room				
└ Antifrost				
1.4.1	[2-06]	Activation	R/W	0: No 1: Yes
1.4.2	[2-05]	Room setpoint	R/W	4~16°C, step: 1°C 8°C
└ Setpoint range				
1.5.1	[3-07]	Heating minimum	R/W	12~18°C, step: 1°C 12°C
1.5.2	[3-06]	Heating maximum	R/W	18~30°C, step: 1°C 30°C
1.5.3	[3-09]	Cooling minimum	R/W	15~25°C, step: 1°C 15°C
1.5.4	[3-08]	Cooling maximum	R/W	25~35°C, step: 1°C 35°C
Room				
1.6	[2-09]	Room sensor offset	R/W	-5~5°C, step: 0,5°C 0°C
1.7	[2-0A]	Room sensor offset	R/W	-5~5°C, step: 0,5°C 0°C
└ Room comfort setpoint				
1.9.1	[9-0A]	Heating comfort setpoint	R/W	[3-07]~[3-06]°C, step: 0,5°C 23°C
1.9.2	[9-0B]	Cooling comfort setpoint	R/W	[3-09]~[3-08]°C, step: 0,5°C 23°C
Main zone				
2.4		Setpoint mode		0: Fixed 1: WD heating, fixed cooling 2: Weather dependent
└ Heating WD curve				
2.5	[1-00]	Low ambient temp. for LWT main zone heating WD curve.	R/W	-40~5°C, step: 1°C -15°C
2.5	[1-01]	High ambient temp. for LWT main zone heating WD curve.	R/W	10~25°C, step: 1°C 15°C
2.5	[1-02]	Leaving water value for low ambient temp. for LWT main zone heating WD curve.	R/W	[9-01]~[9-00], step: 1°C [2-0C]=0 35°C [2-0C]=1 45°C [2-0C]=2 65°C
2.5	[1-03]	Leaving water value for high ambient temp. for LWT main zone heating WD curve.	R/W	[9-01]~min(45, [9-00])°C, step: 1°C [2-0C]=0 25°C [2-0C]=1 35°C [2-0C]=2 35°C
└ Cooling WD curve				
2.6	[1-06]	Low ambient temp. for LWT main zone cooling WD curve.	R/W	10~25°C, step: 1°C 20°C
2.6	[1-07]	High ambient temp. for LWT main zone cooling WD curve.	R/W	25~43°C, step: 1°C 35°C
2.6	[1-08]	Leaving water value for low ambient temp. for LWT main zone cooling WD curve.	R/W	[9-03]~[9-02]°C, step: 1°C 22°C
2.6	[1-09]	Leaving water value for high ambient temp. for LWT main zone cooling WD curve.	R/W	[9-03]~[9-02]°C, step: 1°C [2-0C]=0 18°C [2-0C]=1 7°C [2-0C]=2 18°C
Main zone				

(*1) *X* (*2) *H* (*3) *B* (*4) *EKECBUA*3V_
 (*5) *EKECBUA*6V_* (*6) *EKECBUA*9W_* (*7) BUH less_
 (*8) 300L tank_* (*9) E_* (*10) E7

Field settings table				
Breadcrumb	Setting name		Range, step	Default value
2.7	[2-0C]	Emitter type	R/W	0: Underfloor heating 1: Fancoil unit 2: Radiator
└ Setpoint range				
2.8.1	[9-01]	Heating minimum	R/W	15~37°C, step: 1°C 25°C
2.8.2	[9-00]	Heating maximum	R/W ([2-0C] ≠ 2) R/O ([2-0C] = 2)	[2-0C]=2: 37~70, step: 1°C 70°C [2-0C]≠2: 37~55, step: 1°C 55°C
2.8.3	[9-03]	Cooling minimum	R/W	5~18°C, step: 1°C 7°C
2.8.4	[9-02]	Cooling maximum	R/W	18~22°C, step: 1°C 22°C
Main zone				
2.9	[C-07]	Control	R/W	0: Leaving water 1: External room thermostat 2: Room thermostat
2.A	[C-05]	Ext Thermostat type	R/W	1: 1 contact 2: 2 contacts
└ Delta T				
2.B.1	[1-0B]	Delta T heating	R/W(*10) [2-0D]=2 R/O(*9)	3~10°C, step: 1°C (*9) [2-0C] ≠ 2 (Radiator) 3~12°C, step: 1°C (*10) 5°C [2-0C] = 2 (Radiator) 10~12°C, step: 1°C (*10) 10°C
2.B.2	[1-0D]	Delta T cooling	R/W	3~10°C, step: 1°C 5°C
└ Modulation				
2.C.1	[8-05]	Modulation	R/W	0: No 1: Yes
2.C.2	[8-06]	Max modulation	R/W	0~10°C, step: 1°C 5°C
└ Shut off valve				
2.D.1	[F-0B]	During thermo	R/W	0: No 1: Yes
2.D.2	[F-0C]	During cooling	R/W	0: No (*10) 1: Yes (*9)
Main zone				
2.E		WD curve type	R/W	0: 2-points 1: Slope-Offset
Additional zone				
3.4		Setpoint mode		0: Fixed 1: WD heating, fixed cooling 2: Weather dependent
└ Heating WD curve				
3.5	[0-00]	Leaving water value for high ambient temp. for LWT add zone heating WD curve.	R/W	[9-05]~min(45,[9-06])°C, step: 1°C [2-0C]=0 25°C [2-0C]=1 35°C [2-0C]=2 35°C
3.5	[0-01]	Leaving water value for low ambient temp. for LWT add zone heating WD curve.	R/W	[9-05]~[9-06]°C, step: 1°C [2-0C]=0 35°C [2-0C]=1 45°C [2-0C]=2 65°C

(*1) *X_(2) *H_(3) *B_(4) *EKECBUA*3V_
(*5) *EKECBUA*6V_(6) *EKECBUA*9W_(7) BUH less_
(*8) 300L tank_(9) E_(10) E7

Field settings table				
Breadcrumb	Setting name			Range, step Default value
3.5	[0-02]	High ambient temp. for LWT add zone heating WD curve.	R/W	10~25°C, step: 1°C 15°C
3.5	[0-03]	Low ambient temp. for LWT add zone heating WD curve.	R/W	-40~5°C, step: 1°C -15°C
└─ Cooling WD curve				
3.6	[0-04]	Leaving water value for high ambient temp. for LWT add zone cooling WD curve.	R/W	[9-07]~[9-08]°C, step: 1°C <u>[2-0C]=0</u> 18°C <u>[2-0C]=1</u> 7°C <u>[2-0C]=2</u> 18°C
3.6	[0-05]	Leaving water value for low ambient temp. for LWT add zone cooling WD curve.	R/W	[9-07]~[9-08]°C, step: 1°C 22°C
3.6	[0-06]	High ambient temp. for LWT add zone cooling WD curve.	R/W	25~43°C, step: 1°C 35°C
3.6	[0-07]	Low ambient temp. for LWT add zone cooling WD curve.	R/W	10~25°C, step: 1°C 20°C
Additional zone				
3.7	[2-0D]	Emitter type	R/O	0: Underfloor heating 1: Fancoil unit 2: Radiator
└─ Setpoint range				
3.8.1	[9-05]	Heating minimum	R/W	15~37°C, step: 1°C 25°C
3.8.2	[9-06]	Heating maximum	R/W ([2-0C] ≠ 2) R/O ([2-0C] = 2)	[2-0C]=2: 37~70, step: 1°C 70°C [2-0C]≠2: 37~55, step: 1°C 55°C
3.8.3	[9-07]	Cooling minimum	R/W	5~18°C, step: 1°C 7°C
3.8.4	[9-08]	Cooling maximum	R/W	18~22°C, step: 1°C 22°C
Additional zone				
3.A	[C-06]	Thermostat type	R/W	1: 1 contact 2: 2 contacts
└─ Delta T				
3.B.1	[1-0C]	Delta T heating	R/W(*10) [2-0D]=2 R/O(*9)	3~10°C, step: 1°C (*9) [2-0C] ≠ 2 (Radiator) 3~12°C, step: 1°C (*10) 5°C [2-0C] = 2 (Radiator) 10~12°C, step: 1°C (*10) 10°C
3.B.2	[1-0E]	Delta T cooling	R/W	3~10°C, step: 1°C 5°C
Additional zone				
3.C		WD curve type	R/O	0: 2-points 1: Slope-Offset
Space heating / cooling				
└─ Operation range				
4.3.1	[4-02]	Space heating OFF temp	R/W	14~35°C, step: 1°C 35°C
4.3.2	[F-01]	Space cooling OFF temp	R/W	10~35°C, step: 1°C 20°C
Space heating / cooling				
4.4	[7-02]	Number of zones	R/W	0: Single zone 1: Dual zone
4.5	[F-0D]	Pump operation mode	R/W	0: Continuous 1: Sample 2: Request
4.6	[E-02]	Unit type	R/W(*1) R/O(*2)	0: Reversible(*1) 1: Heating only(*2)

(*1) *X*(*2) *H*(*3) *B*(*4) *EKECBUA*3V_
(*5) *EKECBUA*6V_(*6) *EKECBUA*9W_(*7) BUH less_
(*8) 300L tank_(*9) E_(*10) E7

Field settings table				
Breadcrumb	Setting name		Range, step	Default value
4.7	[9-0D]	Pump speed limitation	R/W	0~8, step:1 0 : No limitation 1~4 : 90~60% pump speed 5~8 : 90~60% pump speed during sampling 6 80% pump speed
Space heating / cooling				
4.9	[F-00]	Pump outside range	R/W	0: Restricted 1: Allowed
4.A	[D-03]	Increase around 0°C	R/W	0: No 1: increase 2°C, span 4°C 2: increase 4°C, span 4°C 3: increase 2°C, span 8°C 4: increase 4°C, span 8°C
4.B	[9-04]	Overshoot	R/W	1~4°C, step: 1°C 1°C (*10) 2°C (*9)
4.C	[2-06]	Antifrost	R/W	0: No 1: Yes
Tank				
5.2	[6-0A]	Comfort setpoint	R/W	30~[6-0E]°C, step: 1°C 60°C
5.3	[6-0B]	Eco setpoint	R/W	30~min(50, [6-0E])°C, step: 1°C 45°C
5.4	[6-0C]	Reheat setpoint	R/W	30~min(50, [6-0E])°C, step: 1°C 45°C
5.6	[6-0D]	Heat up mode	R/W	0: Reheat only 3 scheduled reheat
└ Disinfection				
5.7.1	[2-01]	Activation	R/W	0: No 1: Yes
5.7.2	[2-00]	Operation day	R/W	0: Each day 1: Monday 2: Tuesday 3: Wednesday 4: Thursday 5: Friday 6: Saturday 7: Sunday
5.7.3	[2-02]	Start time	R/W	0~23 hour, step: 1 hour 1
5.7.4	[2-03]	Tank setpoint	R/W	60°C 60°C
5.7.5	[2-04]	Duration	R/W	40~60 min, step: 5 min 40 min
Tank				
5.8	[6-0E]	Maximum	R/W	E-07 = 4 40~ 75°C, step: 1°C 65°C
5.9	[6-00]	Hysteresis	R/W	2~40°C, step: 1°C 8°C
5.A	[6-08]	Reheat hysteresis	R/W	2~20°C, step: 1°C 10°C
5.B		Setpoint mode	R/W	0: Fixed 1: Weather dependent
└ WD curve				
5.C	[0-0B]	Leaving water value for high ambient temp. for DHW WD curve.	R/W	35~[6-0E]°C, step: 1°C 55°C
5.C	[0-0C]	Leaving water value for low ambient temp. for DHW WD curve.	R/W	Min(45~[6-0E])~[6-0E]°C, step: 1°C 60°C
5.C	[0-0D]	High ambient temp. for DHW WD curve.	R/W	10~25°C, step: 1°C 15°C
5.C	[0-0E]	Low ambient temp. for DHW WD curve.	R/W	-40~5°C, step: 1°C -10°C
Tank				

(*1) *X_(2) *H_(3) *B_(4) *EKECBUA*3V_
 (*5) *EKECBUA*6V_(6) *EKECBUA*9W_(7) BUH less_
 (*8) 300L tank_(9) E_(10) E7

Field settings table				
Breadcrumb	Setting name		Range, step	Default value
5.D	[6-01]	Margin	R/W	0~10°C, step: 1°C 0°C
5.E		WD curve type	R/O	0: 2-points 1: Slope-Offset
User settings				
└ Quiet				
7.4.1		mode	R/W	0: OFF 1: Manual 2: Automatic
7.4.3		Level	R/W	0: Quiet 1: More Quiet 2: Most Quiet
└ Electricity price				
7.5.1		High	R/W	0,00~990/kWh 1/kWh
7.5.2		Medium	R/W	0,00~990/kWh 1/kWh
7.5.3		Low	R/W	0,00~990/kWh 1/kWh
User settings				
7.6		Gas price	R/W	0,00~990/kWh 0,00~290/MBtu 1,0/kWh
Installer settings				
└ Configuration wizard				
└ System				
9.1.3.2	[E-03]	BUH type	R/W	0: no heater (*7) 2: 3V (*4) 3: 6V (*5) 4: 9W (*6)
9.1.3.3	[E-05] [E-06] [E-07]	Domestic hot water	R/O	Integrated'
9.1.3.4	[4-06]	Emergency	R/W	0: Manual 1: Automatic 2: Auto SH reduced/ DHW ON 3: Auto SH reduced/ DHW OFF 4: Auto SH normal/ DHW OFF
9.1.3.5	[7-02]	Number of zones	R/W	0: Single zone 1: Dual zone
9.1.3.6	[E-0D]	Glycol Filled system	R/W	0: No 1: Yes
9.1.3.7	[6-02]	BSH capacity	R/W	0~10kW, step: 0,2kW 0kW
9.1.3.8	[C-02]	Bivalent	R/W	0: Off 1: Direct (SH) 2: Indirect (DHW) (*3) 3: Indirect (DHW + SH)
9.2.4	[D-07]	Solar	R/W	0: No 1: Yes (DHW) 2: Yes (DHW + SH)
└ Backup heater				
9.1.4.1	[5-0D]	Voltage	R/W	0: 230V, 1~ (*4, *5, *7) 2: 400V, 3~ (*6)
9.1.4.2	[4-0A]	Configuration	R/W (*5, *6, *7) R/O (*4)	0: 1 (*4, *7) 1: 1/1+2 (*5, *6) 2: 1/2 3: 1/2 + 1/1+2 in emergency
9.1.4.3	[6-03]	Capacity step 1	R/O	0~10kW, step: 0,2kW 0kW 2kW (*5) 3kW (*4, *6, *7)

(*1) *X* (*2) *H* (*3) *B* (*4) *EKEC BUA*3V_
(*5) *EKEC BUA*6V_* (*6) *EKEC BUA*9W_* (*7) BUH less_
(*8) 300L tank_* (*9) E_* (*10) E7

Field settings table				
Breadcrumb	Setting name		Range, step	Default value
9.1.4.4	[6-04]	Additional capacity step 2	R/W (*5, *6) R/O (*4, *7)	0~10kW, step: 0,2kW 0kW (*4) 3kW (*7) 4kW (*5) 6kW (*6)
└ Main zone				
9.1.5.1	[2-0C]	Emitter type	R/W	0: Underfloor heating 1: Fancoil unit 2: Radiator
9.1.5.2	[C-07]	Control	R/W	0: Leaving water 1: External room thermostat 2: Room thermostat
9.1.5.3		Setpoint mode	R/W	0: Fixed 1: WD heating, fixed cooling 2: Weather dependent
9.1.5.4		Schedule	R/W	0: No 1: Yes
9.1.5.5		WD curve type	R/W	0: 2-points 1: Slope-Offset
9.1.6	[1-00]	Low ambient temp. for LWT main zone heating WD curve.	R/W	-40~5°C, step: 1°C -15°C
9.1.6	[1-01]	High ambient temp. for LWT main zone heating WD curve.	R/W	10~25°C, step: 1°C 15°C
9.1.6	[1-02]	Leaving water value for low ambient temp. for LWT main zone heating WD curve.	R/W	[9-01]~[9-00], step: 1°C <u>[2-0C]=0</u> 35°C <u>[2-0C]=1</u> 45°C <u>[2-0C]=2</u> 65°C
9.1.6	[1-03]	Leaving water value for high ambient temp. for LWT main zone heating WD curve.	R/W	[9-01]~min(45, [9-00])°C, step: 1°C <u>[2-0C]=0</u> 25°C <u>[2-0C]=1</u> 35°C <u>[2-0C]=2</u> 35°C
9.1.7	[1-06]	Low ambient temp. for LWT main zone cooling WD curve.	R/W	10~25°C, step: 1°C 20°C
9.1.7	[1-07]	High ambient temp. for LWT main zone cooling WD curve.	R/W	25~43°C, step: 1°C 35°C
9.1.7	[1-08]	Leaving water value for low ambient temp. for LWT main zone cooling WD curve.	R/W	[9-03]~[9-02]°C, step: 1°C 22°C
9.1.7	[1-09]	Leaving water value for high ambient temp. for LWT main zone cooling WD curve.	R/W	[9-03]~[9-02]°C, step: 1°C <u>[2-0C]=0</u> 18°C <u>[2-0C]=1</u> 7°C <u>[2-0C]=2</u> 18°C
└ Additional zone				
9.1.8.1	[2-0D]	Emitter type	R/W	0: Underfloor heating 1: Fancoil unit 2: Radiator
9.1.8.3		Setpoint mode	R/W	0: Fixed 1: WD heating, fixed cooling 2: Weather dependent
9.1.8.4		Schedule	R/W	0: No 1: Yes

(*1) *X*_(2) *H*_(3) *B*_(4) *EKECBUA*3V_
(*5) *EKECBUA*6V_(6) *EKECBUA*9W_(7) BUH less_
(*8) 300L tank_(9) E_(10) E7

Field settings table				
Breadcrumb	Setting name			Range, step Default value
9.1.9	[0-00]	Leaving water value for high ambient temp. for LWT add zone heating WD curve.	R/W	[9-05]~min(45,[9-06])°C, step: 1°C [2-0C]=0 25°C [2-0C]=1 35°C [2-0C]=2 35°C
9.1.9	[0-01]	Leaving water value for low ambient temp. for LWT add zone heating WD curve.	R/W	[9-05]~[9-06]°C, step: 1°C [2-0C]=0 35°C [2-0C]=1 45°C [2-0C]=2 65°C
9.1.9	[0-02]	High ambient temp. for LWT add zone heating WD curve.	R/W	10~25°C, step: 1°C 15°C
9.1.9	[0-03]	Low ambient temp. for LWT add zone heating WD curve.	R/W	-40~5°C, step: 1°C -15°C
9.1.A	[0-04]	Leaving water value for high ambient temp. for LWT add zone cooling WD curve.	R/W	[9-07]~[9-08]°C, step: 1°C [2-0C]=0 18°C [2-0C]=1 7°C [2-0C]=2 18°C
9.1.A	[0-05]	Leaving water value for low ambient temp. for LWT add zone cooling WD curve.	R/W	[9-07]~[9-08]°C, step: 1°C 22°C
9.1.A	[0-06]	High ambient temp. for LWT add zone cooling WD curve.	R/W	25~43°C, step: 1°C 35°C
9.1.A	[0-07]	Low ambient temp. for LWT add zone cooling WD curve.	R/W	10~25°C, step: 1°C 20°C
└ Tank				
9.1.B.1	[6-0D]	Heat up mode	R/W	0: Reheat only 3 scheduled reheat
9.1.B.2	[6-0A]	Comfort setpoint	R/W	30~[6-0E]°C, step: 1°C 60°C
9.1.B.3	[6-0B]	Eco setpoint	R/W	30~min(50, [6-0E])°C, step: 1°C 45°C
9.1.B.4	[6-0C]	Reheat setpoint	R/W	30~min(50, [6-0E])°C, step: 1°C 45°C
9.1.B.5	[6-08]	Reheat hysteresis	R/W	2~20°C, step: 1°C 10°C
└ Domestic hot water				
9.2.1	[E-05] [E-06] [E-07]	Domestic hot water	R/O	Integrated'
9.2.2	[D-02]	DHW pump	R/W	0: No DHW pump 1: Instant hot water 2: Disinfection 3: Circulation 4: Circulation and disinfection
9.2.4	[D-07]	Solar	R/W	0: No 1: Yes (DHW) 2: Yes (DHW + SH)
└ Back up heater				
9.3.1	[E-03]	BUH type	R/W	0: no heater (*7) 2: 3V (*4) 3: 6V (*5) 4: 9W (*6)
9.3.2	[5-0D]	Voltage	R/W	0: 230V, 1~ (*4, *5, *7) 2: 400V, 3~ (*6)
9.3.3	[4-0A]	Configuration	R/W (*5, *6, *7) R/O (*4)	0: 1 (*4, *7) 1: 1/1+2 (*5, *6) 2: 1/2 3: 1/2 + 1/1+2 in emergency

(*1) *X_*(*2) *H_*(*3) *B_*(*4) *EKECBUA*3V_
(*5) *EKECBUA*6V_*(*6) *EKECBUA*9W_*(*7) BUH less_
(*8) 300L tank_*(*9) E_*(*10) E7

Field settings table				
Breadcrumb	Setting name		Range, step	Default value
9.3.4	[6-03]	Capacity step 1	R/W	0~10kW, step: 0,2kW 0kW 2kW (*5) 3kW (*4, *6, *7)
9.3.5	[6-04]	Additional capacity step 2	R/W (*5, *6) R/O (*4, *7)	0~10kW, step: 0,2kW 0kW (*4) 3kW (*7) 4kW (*5) 6kW (*6)
9.3.6	[5-00]	Equilibrium: Deactivate backup heater (or external backup heat source in case of a bivalent system) above the equilibrium temperature for space heating?	R/W	0: No (*10) 1: Yes (*9)
9.3.7	[5-01]	Equilibrium temperature	R/W	-15~35°C, step: 1°C 0°C
9.3.8	[4-00]	Operation	R/W	0: Restricted 1: Allowed 2: Only DHW
└ Booster heater				
9.4.1	[6-02]	Capacity	R/W	0~10kW, step: 0,2kW 0kW
9.4.3	[8-03]	BSH eco timer	R/W	20~95 min, step: 5 min 50 min
9.4.4	[4-03]	Operation	R/W	0: Restricted 1: Allowed 2: Overlap 3: Compressor off 4: Legionella only
└ Emergency				
9.5.1	[4-06]	Emergency	R/W	0: Manual 1: Automatic 2: Auto SH reduced/ DHW ON 3: Auto SH reduced/ DHW OFF 4: Auto SH normal/ DHW OFF
9.5.2	[7-06]	HP forced OFF	R/W	0: Disabled 1: Enabled
└ Balancing				
9.6.1	[5-02]	Space heating priority	R/W	0: Disabled 1: Enabled
9.6.2	[5-03]	Priority temperature	R/W	-15~35°C, step: 1°C 0°C
9.6.3	[5-04]	Offset BSH setpoint	R/W	0~20°C, step: 1°C 10°C
9.6.4	[8-02]	Anti-recycle timer	R/W	0~10 hour, step: 0,5 hour 0,5 hour
9.6.5	[8-00]	Minimum running timer	R/O	0~20 min, step 1 min 1 min
9.6.6	[8-01]	Maximum running timer	R/W	5~95 min, step: 5 min 30 min
9.6.7	[8-04]	Additional timer	R/W	0~95 min, step: 5 min 95 min
Installer settings				
9.7	[4-04]	Water pipe freeze prevention	R/W	0: Continuous pump operation 1: Non continuous pump operation 2: OFF
└ Benefit kWh power supply				
9.8.2	[D-00]	Allow heater	R/W	0: No 1: Only BSH 2: Only BUH 3: All
9.8.3	[D-05]	Allow pump	R/W	0: No 1: Yes

(*1) *X_(2) *H_(3) *B_(4) *EKECBUA*3V_
(*5) *EKECBUA*6V_(6) *EKECBUA*9W_(7) BUH less_
(*8) 300L tank_(9) E_(10) E7

Field settings table

Breadcrumb	Setting name	Range, step	Default value
9.8.4	[D-01]	Benefit kWh power supply	R/W 0: No 1: Open 2: Closed 3: Smart Grid
9.8.6		Allow electric heaters	R/W 0: No 1: Yes
9.8.7		Enable Room buffering	R/W 0: No 1: Yes
9.8.8		Limit setting kW	R/W 0~20 kW, step: 0,5 kW 2 kW
└─ Power consumption control			
9.9.1	[4-08]	Power consumption control	R/W 0: No 1: Continuous 2: Inputs 3: Current Sensor
9.9.2	[4-09]	Type	R/W 0: Amp 1: kW
9.9.3	[5-05]	Limit	R/W 0~50 A, step: 1 A 50 A
9.9.4	[5-05]	Limit 1	R/W 0~50 A, step: 1 A 50 A
9.9.5	[5-06]	Limit 2	R/W 0~50 A, step: 1 A 50 A
9.9.6	[5-07]	Limit 3	R/W 0~50 A, step: 1 A 50 A
9.9.7	[5-08]	Limit 4	R/W 0~50 A, step: 1 A 50 A
9.9.8	[5-09]	Limit	R/W 0~20 kW, step: 0,5 kW 20 kW
9.9.9	[5-09]	Limit 1	R/W 0~20 kW, step: 0,5 kW 20 kW
9.9.A	[5-0A]	Limit 2	R/W 0~20 kW, step: 0,5 kW 20 kW
9.9.B	[5-0B]	Limit 3	R/W 0~20 kW, step: 0,5 kW 20 kW
9.9.C	[5-0C]	Limit 4	R/W 0~20 kW, step: 0,5 kW 20 kW
9.9.D	[4-01]	Priority heater	R/W 0: None 1: Booster Heater 2: Backup Heater
9.9.F	[7-07]	BBR16 activation* *BBR16 settings are only visible when the language of the user interface is set to Swedish.	R/W 0: No 1: Yes
└─ Energy metering			
9.A.1	[D-08]	Electricity meter 1	R/W 0: No 1: 0,1 pulse/kWh 2: 1 pulse/kWh 3: 10 pulse/kWh 4: 100 pulse/kWh 5: 1000 pulse/kWh
9.A.2	[D-09]	Electricity meter 2 / PV meter	R/W 0: No 1: 0,1 pulse/kWh 2: 1 pulse/kWh 3: 10 pulse/kWh 4: 100 pulse/kWh 5: 1000 pulse/kWh 6: 100 pulse/kWh (PV meter) 7: 1000 pulse/kWh (PV meter)
└─ Sensors			
9.B.1	[C-08]	External sensor	R/W 0: No 1: Outdoor 2: Room
9.B.2	[2-0B]	Ext. amb. sensor offset	R/W -5~5°C, step: 0,5°C 0°C

(*1) *X* (*2) *H* (*3) *B* (*4) *EKECBUA*3V_
 (*5) *EKECBUA*6V_* (*6) *EKECBUA*9W_* (*7) BUH less_
 (*8) 300L tank_* (*9) E_* (*10) E7

Field settings table

Breadcrumb	Setting name	Range, step	Default value
9.B.3	[1-0A]	Averaging time	R/W 0: No 1: 12 h 2: 24 h 3: 48 h 4: 72 h
└ Bivalent			
9.C.1	[C-02]	Bivalent	R/W 0: Off 1: Direct (SH) 2: Indirect (DHW) (*3) 3: Indirect (DHW + SH)
9.C.2	[7-05]	Boiler efficiency	R/W 0: Very high 1: High 2: Medium 3: Low 4: Very low
9.C.3	[C-03]	Temperature	R/W -25~25°C, step: 1°C 0°C
9.C.4	[C-04]	Hysteresis	R/W 2~10°C, step 1°C 3°C
Installer settings			
9.D	[C-09]	Alarm output	R/W 0: Abnormal 1: Normal
9.E	[3-00]	Auto restart	R/W 0: manual 1: automatic
9.F	[E-08]	Power saving function	R/W 0: No 1: Yes
9.G		Disable protections	R/W 0: No 1: Yes
└ Overview field settings			
9.I	[0-00]	Leaving water value for high ambient temp. for LWT add zone heating WD curve.	R/W [9-05]~min(45,[9-06])°C, step: 1°C [2-0C]=0 25°C [2-0C]=1 35°C [2-0C]=2 35°C
9.I	[0-01]	Leaving water value for low ambient temp. for LWT add zone heating WD curve.	R/W [9-05]~[9-06]°C, step: 1°C [2-0C]=0 35°C [2-0C]=1 45°C [2-0C]=2 65°C
9.I	[0-02]	High ambient temp. for LWT add zone heating WD curve.	R/W 10~25°C, step: 1°C 15°C
9.I	[0-03]	Low ambient temp. for LWT add zone heating WD curve.	R/W -40~5°C, step: 1°C -15°C
9.I	[0-04]	Leaving water value for high ambient temp. for LWT add zone cooling WD curve.	R/W [9-07]~[9-08]°C, step: 1°C [2-0C]=0 18°C [2-0C]=1 7°C [2-0C]=2 18°C
9.I	[0-05]	Leaving water value for low ambient temp. for LWT add zone cooling WD curve.	R/W [9-07]~[9-08]°C, step: 1°C 22°C
9.I	[0-06]	High ambient temp. for LWT add zone cooling WD curve.	R/W 25~43°C, step: 1°C 35°C
9.I	[0-07]	Low ambient temp. for LWT add zone cooling WD curve.	R/W 10~25°C, step: 1°C 20°C
9.I	[0-0B]	Leaving water value for high ambient temp. for DHW WD curve.	R/W 35~[6-0E]°C, step: 1°C 55°C
9.I	[0-0C]	Leaving water value for low ambient temp. for DHW WD curve.	R/W Min(45~[6-0E])~[6-0E]°C, step: 1°C 60°C

(*1) *X*_(*2) *H*_(*3) *B*_(*4) *EKECBUA*3V_
 (*5) *EKECBUA*6V_(*6) *EKECBUA*9W_(*7) BUH less_
 (*8) 300L tank_(*9) E_(*10) E7

Field settings table

Breadcrumb	Setting name	Range, step Default value
9.1	[0-0D]	High ambient temp. for DHW WD curve. R/W 10~25°C, step: 1°C 15°C
9.1	[0-0E]	Low ambient temp. for DHW WD curve. R/W -40~5°C, step: 1°C -10°C
9.1	[1-00]	Low ambient temp. for LWT main zone heating WD curve. R/W -40~5°C, step: 1°C -15°C
9.1	[1-01]	High ambient temp. for LWT main zone heating WD curve. R/W 10~25°C, step: 1°C 15°C
9.1	[1-02]	Leaving water value for low ambient temp. for LWT main zone heating WD curve. R/W [9-01]~[9-00], step: 1°C <u>[2-0C]=0</u> 35°C <u>[2-0C]=1</u> 45°C <u>[2-0C]=2</u> 65°C
9.1	[1-03]	Leaving water value for high ambient temp. for LWT main zone heating WD curve. R/W [9-01]~min(45, [9-00])°C, step: 1°C <u>[2-0C]=0</u> 25°C <u>[2-0C]=1</u> 35°C <u>[2-0C]=2</u> 35°C
9.1	[1-04]	Weather dependent cooling of the main leaving water temperature zone. R/W 0: Disabled 1: Enabled
9.1	[1-05]	Weather dependent cooling of the additional leaving water temperature zone R/W 0: Disabled 1: Enabled
9.1	[1-06]	Low ambient temp. for LWT main zone cooling WD curve. R/W 10~25°C, step: 1°C 20°C
9.1	[1-07]	High ambient temp. for LWT main zone cooling WD curve. R/W 25~43°C, step: 1°C 35°C
9.1	[1-08]	Leaving water value for low ambient temp. for LWT main zone cooling WD curve. R/W [9-03]~[9-02]°C, step: 1°C 22°C
9.1	[1-09]	Leaving water value for high ambient temp. for LWT main zone cooling WD curve. R/W [9-03]~[9-02]°C, step: 1°C <u>[2-0C]=0</u> 18°C <u>[2-0C]=1</u> 7°C <u>[2-0C]=2</u> 18°C
9.1	[1-0A]	What is the averaging time for the outdoor temp? R/W 0: No 1: 12 h 2: 24 h 3: 48 h 4: 72 h
9.1	[1-0B]	What is the desired delta T in heating for the main zone? R/W(*10) [2-0D]=2 R/O (*9) 3~10°C, step: 1°C (*9) [2-0C] ≠ 2 (Radiator) 3~12°C, step: 1°C (*10) 5°C [2-0C] = 2 (Radiator) 10~12°C, step: 1°C (*10) 10°C
9.1	[1-0C]	What is the desired delta T in heating for the additional zone? R/W(*10) [2-0D]=2 R/O (*9) 3~10°C, step: 1°C (*9) [2-0C] ≠ 2 (Radiator) 3~12°C, step: 1°C (*10) 5°C [2-0C] = 2 (Radiator) 10~12°C, step: 1°C (*10) 10°C
9.1	[1-0D]	What is the desired delta T in cooling for the main zone? R/W 3~10°C, step: 1°C 5°C
9.1	[1-0E]	What is the desired delta T in cooling for the additional zone? R/W 3~10°C, step: 1°C 5°C

(*1) *X* (*2) *H* (*3) *B* (*4) *EKECBUA*3V_
 (*5) *EKECBUA*6V_* (*6) *EKECBUA*9W_* (*7) BUH less_
 (*8) 300L tank_* (*9) E_* (*10) E7

Field settings table

Breadcrumb	Setting name	Range, step	Default value
9.1	[2-00]	When should the disinfection function be executed?	R/W 0: Each day 1: Monday 2: Tuesday 3: Wednesday 4: Thursday 5: Friday 6: Saturday 7: Sunday
9.1	[2-01]	Should the disinfection function be executed?	R/W 0: No 1: Yes
9.1	[2-02]	When should the disinfection function start?	R/W 0~23 hour, step: 1 hour 1
9.1	[2-03]	What is the disinfection target temperature?	R/W 60°C 60°C
9.1	[2-04]	How long must the tank temperature be maintained?	R/W 40~60 min, step: 5 min 40 min
9.1	[2-05]	Room antifrost temperature	R/W 4~16°C, step: 1°C 8°C
9.1	[2-06]	Room frost protection	R/W 0: No 1: Yes
9.1	[2-09]	Adjust the offset on the measured room temperature	R/W -5~5°C, step: 0,5°C 0°C
9.1	[2-0A]	Adjust the offset on the measured room temperature	R/W -5~5°C, step: 0,5°C 0°C
9.1	[2-0B]	What is the required offset on the measured outdoor temp.?	R/W -5~5°C, step: 0,5°C 0°C
9.1	[2-0C]	What emitter type is connected to the main LWT zone?	R/W 0: Underfloor heating 1: Fancoil unit 2: Radiator
9.1	[2-0D]	What emitter type is connected to the additional LWT zone?	R/W 0: Underfloor heating 1: Fancoil unit 2: Radiator
9.1	[2-0E]	What is the maximum allowed current over the heatpump ?	R/W 20~50 A, step: 1 A 50 A
9.1	[3-00]	Is auto restart of the unit allowed?	R/W 0: manual 1: automatic
9.1	[3-01]	--	R/W 0
9.1	[3-02]	--	R/W 1
9.1	[3-03]	--	R/W 4
9.1	[3-04]	--	R/W 2
9.1	[3-05]	--	R/W 1
9.1	[3-06]	What is the maximum desired room temperature in heating?	R/W 18~30°C, step: 1°C 30°C
9.1	[3-07]	What is the minimum desired room temperature in heating?	R/W 12~18°C, step: 1°C 12°C
9.1	[3-08]	What is the maximum desired room temperature in cooling?	R/W 25~35°C, step: 1°C 35°C
9.1	[3-09]	What is the minimum desired room temperature in cooling?	R/W 15~25°C, step: 1°C 15°C
9.1	[3-0A]	--	0
9.1	[3-0B]	--	1
9.1	[3-0C]	--	1
9.1	[3-0D]	In case a bizona kit is installed, antiblockage of kit pump(s) and kit mixing valve	R/W 0: Disabled (*10) 1: Enabled
9.1	[4-00]	What is the BUH operation mode?	R/W 0: Restricted 1: Allowed 2: Only DHW
9.1	[4-01]	Which electric heater has priority?	R/W 0: None 1: Booster Heater 2: Backup Heater
9.1	[4-02]	Below which outdoor temperature is heating allowed?	R/W 14~35°C, step: 1°C 35°C

(*1) *X_(2) *H_(3) *B_(4) *EKECBUA*3V_
 (*5) *EKECBUA*6V_(6) *EKECBUA*9W_(7) BUH less_
 (*8) 300L tank_(9) E_(10) E7

Field settings table

Breadcrumb	Setting name	Range, step Default value
9.1	[4-03]	Operation permission of the booster heater. R/W 0: Restricted 1: Allowed 2: Overlap 3: Compressor off 4: Legionella only
9.1	[4-04]	Water pipe freeze prevention R/W 0: Continuous pump operation 1: Non continuous pump operation 2: OFF
9.1	[4-05]	-- 0
9.1	[4-06]	Emergency R/W 0: Manual 1: Automatic 2: Auto SH reduced/ DHW ON 3: Auto SH reduced/ DHW OFF 4: Auto SH normal/ DHW OFF
9.1	[4-07]	-- 3
9.1	[4-08]	Which power limitation mode is required on the system? R/W 0: No 1: Continuous 2: Inputs 3: Current Sensor
9.1	[4-09]	Which power limitation type is required? R/W 0: Amp 1: kW
9.1	[4-0A]	Backup heater configuration R/W (*5, *6, *7) R/O (*4) 0: 1 (*4, *7) 1: 1/1+2 (*5, *6) 2: 1/2 3: 1/2 + 1/1+2 in emergency
9.1	[4-0B]	Automatic cooling/heating changeover hysteresis. R/W 1~10°C, step: 0,5°C 1°C
9.1	[4-0D]	Automatic cooling/heating changeover offset. R/W 1~10°C, step: 0,5°C 3°C
9.1	[4-0E]	-- 6
9.1	[5-00]	Equilibrium: Deactivate backup heater (or external backup heat source in case of a bivalent system) above the equilibrium temperature for space heating? R/W 0: No (*10) 1: Yes (*9)
9.1	[5-01]	What is the equilibrium temperature for the building? R/W -15~35°C, step: 1°C 0°C
9.1	[5-02]	Space heating priority. R/W 0: Disabled 1: Enabled
9.1	[5-03]	Space heating priority temperature. R/W -15~35°C, step: 1°C 0°C
9.1	[5-04]	Set point correction for domestic hot water temperature. R/W 0~20°C, step: 1°C 10°C
9.1	[5-05]	What is the requested limit for DI1? R/W 0~50 A, step: 1 A 50 A
9.1	[5-06]	What is the requested limit for DI2? R/W 0~50 A, step: 1 A 50 A
9.1	[5-07]	What is the requested limit for DI3? R/W 0~50 A, step: 1 A 50 A
9.1	[5-08]	What is the requested limit for DI4? R/W 0~50 A, step: 1 A 50 A
9.1	[5-09]	What is the requested limit for DI1? R/W 0~20 kW, step: 0,5 kW 20 kW
9.1	[5-0A]	What is the requested limit for DI2? R/W 0~20 kW, step: 0,5 kW 20 kW
9.1	[5-0B]	What is the requested limit for DI3? R/W 0~20 kW, step: 0,5 kW 20 kW
9.1	[5-0C]	What is the requested limit for DI4? R/W 0~20 kW, step: 0,5 kW 20 kW
9.1	[5-0D]	Backup heater voltage R/W 0: 230V, 1~ (*4, *5, *7) 2: 400V, 3~ (*6)
9.1	[5-0E]	-- 1
9.1	[6-00]	The temperature difference determining the heat pump ON temperature. R/W 2~40°C, step: 1°C 8°C

(*1) *X_(*2) *H_(*3) *B_(*4) *EKECBUA*3V_
 (*5) *EKECBUA*6V_(*6) *EKECBUA*9W_(*7) BUH less_
 (*8) 300L tank_(*9) E_(*10) E7

Field settings table

Breadcrumb	Setting name	Range, step Default value
9.1	[6-01]	The temperature difference determining the heat pump OFF temperature. R/W 0~10°C, step: 1°C 0°C
9.1	[6-02]	What is the capacity of the booster heater? R/W 0~10kW, step: 0,2kW 0kW
9.1	[6-03]	What is the capacity of the backup heater step 1? R/O 0~10kW, step: 0,2kW 0kW 2kW (*5) 3kW (*4, *6, *7)
9.1	[6-04]	What is the capacity of the backup heater step 2? R/W (*5, *6) R/O (*4, *7) 0~10kW, step: 0,2kW 0kW (*4) 3kW (*7) 4kW (*5) 6kW (*6)
9.1	[6-07]	-- 0
9.1	[6-08]	What is the hysteresis to be used in reheat mode? R/W 2~20°C, step: 1°C 10°C
9.1	[6-09]	-- 0
9.1	[6-0A]	What is the desired comfort storage temperature? R/W 30~[6-0E]°C, step: 1°C 60°C
9.1	[6-0B]	What is the desired eco storage temperature? R/W 30~min(50, [6-0E])°C, step: 1°C 45°C
9.1	[6-0C]	What is the desired reheat temperature? R/W 30~min(50, [6-0E])°C, step: 1°C 45°C
9.1	[6-0D]	What is the desired DHW production type? R/W 0: Reheat only 3 scheduled reheat
9.1	[6-0E]	What is the maximum temperature setpoint? R/W E-07 = 4 40~ 75°C, step: 1°C 65°C
9.1	[7-00]	Domestic hot water booster heater overshoot temperature. R/W 0~4°C, step: 1°C 0°C
9.1	[7-01]	Domestic hot water booster heater hysteresis. R/W 2~40°C, step: 1°C 2°C
9.1	[7-02]	How many leaving water temperature zones are there? R/W 0: Single zone 1: Dual zone
9.1	[7-03]	-- 2,5
9.1	[7-04]	-- 0
9.1	[7-05]	Boiler efficiency R/W 0: Very high 1: High 2: Medium 3: Low 4: Very low
9.1	[7-06]	HP forced OFF R/W 0: Disabled 1: Enabled
9.1	[7-07]	BBR16 activation* *BBR16 settings are only visible when the language of the user interface is set to Swedish. R/W 0: No 1: Yes
9.1	[7-09]	How much is the minimum pump PWM value. R/W 20%
9.1	[7-0A]	Additional zone fixed pump PWM, in case a bizon kit is installed. R/W 20~95%, step 5% 95%
9.1	[7-0B]	Main zone fixed pump PWM, in case a bizon kit is installed. R/W 20~95%, step 5% 95%
9.1	[7-0C]	Time needed by the mixing valve to turn from one side to the other, in case a bizon kit is installed. R/W 20~300 seconds, step 5 sec 125 seconds
9.1	[7-0D]	Hysteresis value used to control the tank bivalent in case it's supporting space heating operation R/W 2~20, step 0,5 °C 4 °C
9.1	[7-0E]	Offset on the setpoint to determine when the tank is high enough to go the excess state R/W 2~22, step 0,5 °C 7 °C
9.1	[8-00]	Minimum running time for domestic hot water operation. R/W 0~20 min, step 1 min 1 min
9.1	[8-01]	Maximum running time for domestic hot water operation. R/W 5~95 min, step: 5 min 30 min
9.1	[8-02]	Anti-recycling time. R/W 0~10 hour, step: 0,5 hour 0,5 hour

(*1) *X*_(2) *H*_(3) *B*_(4) *EKECBUA*3V_
(*5) *EKECBUA*6V_(6) *EKECBUA*9W_(7) BUH less_
(*8) 300L tank_(9) E_(10) E7

Field settings table

Breadcrumb	Setting name	Range, step	Default value
9.1	[8-03]	Booster heater delay timer.	R/W 20~95 min, step: 5 min 50 min
9.1	[8-04]	Additional running time for the maximum running time.	R/W 0~95 min, step: 5 min 95 min
9.1	[8-05]	Allow modulation of the LWT to control the room temp?	R/W 0: No 1: Yes
9.1	[8-06]	Leaving water temperature maximum modulation.	R/W 0~10°C, step: 1°C 5°C
9.1	[8-07]	What is the desired comfort main LWT in cooling?	R/W [9-03]~[9-02], step: 1°C 18°C
9.1	[8-08]	What is the desired eco main LWT in cooling?	R/W [9-03]~[9-02], step: 1°C 20°C
9.1	[8-09]	What is the desired comfort main LWT in heating?	R/W [9-01]~[9-00], step: 1°C 35°C
9.1	[8-0A]	What is the desired eco main LWT in heating?	R/W [9-01]~[9-00], step: 1°C 33°C
9.1	[8-0B]	--	13
9.1	[8-0C]	--	10
9.1	[8-0D]	--	16
9.1	[9-00]	What is the maximum desired LWT for main zone in heating?	R/W ([2-0C] ≠ 2) 2~20°C, step: 1°C R/O ([2-0C] = 2) 37~70, step: 1°C 70°C [2-0C]≠2: 37~55, step: 1°C 55°C
9.1	[9-01]	What is the minimum desired LWT for main zone in heating?	R/W 15~37°C, step: 1°C 25°C
9.1	[9-02]	What is the maximum desired LWT for main zone in cooling?	R/W 18~22°C, step: 1°C 22°C
9.1	[9-03]	What is the minimum desired LWT for main zone in cooling?	R/W 5~18°C, step: 1°C 7°C
9.1	[9-04]	Leaving water temperature overshoot temperature.	R/W 1~4°C, step: 1°C 1°C (*10) 2°C (*9)
9.1	[9-05]	What is the minimum desired LWT for add. zone in heating?	R/W 15~37°C, step: 1°C 25°C
9.1	[9-06]	What is the maximum desired LWT for add. zone in heating?	R/W ([2-0C] ≠ 2) 2~20°C, step: 1°C R/O ([2-0C] = 2) 37~70, step: 1°C 70°C [2-0C]≠2: 37~55, step: 1°C 55°C
9.1	[9-07]	What is the minimum desired LWT for add. zone in cooling?	R/W 5~18°C, step: 1°C 7°C
9.1	[9-08]	What is the maximum desired LWT for add. zone in cooling?	R/W 18~22°C, step: 1°C 22°C
9.1	[9-09]	What is the allowed LWT undershoot during cooling start-up?	R/W 1~18°C, step: 1°C 18°C
9.1	[9-0A]	What is the room buffering temperature in heating?	R/W [3-07]~[3-06]°C, step: 0,5°C 23°C
9.1	[9-0B]	What is the room buffering temperature in Cooling?	R/W [3-09]~[3-08]°C, step: 0,5°C 23°C
9.1	[9-0C]	Room temperature hysteresis.	R/W 1~6°C, step: 0,5°C 1°C
9.1	[9-0D]	Pump speed limitation	R/W 0~8, step:1 0 : No limitation 1~4 : 90~60% pump speed 5~8 : 90~60% pump speed during sampling 6 80% pump speed
9.1	[9-0E]	--	6
9.1	[C-00]	Domestic heating water priority.	R/W 0: Solar priority 1: Heat pump priority
9.1	[C-01]	--	0

(*1) *X* (*2) *H* (*3) *B* (*4) *EKECBUA*3V_
 (*5) *EKECBUA*6V_ (*6) *EKECBUA*9W_ (*7) BUH less_
 (*8) 300L tank_ (*9) E_ (*10) E7

Field settings table

Breadcrumb	Setting name	Range, step	Default value
9.1	[C-02]	Is an external backup heat source connected?	R/W 0: Off 1: Direct (SH) 2: Indirect (DHW) (*3) 3: Indirect (DHW + SH)
9.1	[C-03]	Bivalent activation temperature.	R/W -25~25°C, step: 1°C 0°C
9.1	[C-04]	Bivalent hysteresis temperature.	R/W 2~10°C, step 1°C 3°C
9.1	[C-05]	What is the thermo request contact type for the main zone?	R/W 1: 1 contact 2: 2 contacts
9.1	[C-06]	What is the thermo request contact type for the add. zone?	R/W 1: 1 contact 2: 2 contacts
9.1	[C-07]	What is the unit control method in space operation?	R/W 0: Leaving water 1: External room thermostat 2: Room thermostat
9.1	[C-08]	Which type of external sensor is installed?	R/W 0: No 1: Outdoor 2: Room
9.1	[C-09]	What is the required alarm output contact type?	R/W 0: Abnormal 1: Normal
9.1	[C-0A]	--	0
9.1	[C-0B]	--	0
9.1	[C-0C]	--	0
9.1	[C-0D]	--	0
9.1	[C-0E]	--	0
9.1	[D-00]	Which heaters are permitted if prefer. kWh rate PS is cut?	R/W 0: No 1: Only BSH 2: Only BUH 3: All
9.1	[D-01]	Contact type of preferential kWh rate PS installation?	R/W 0: No 1: Open 2: Closed 3: Smart Grid
9.1	[D-02]	Which type of DHW pump is installed?	R/W 0: No DHW pump 1: Instant hot water 2: Disinfection 3: Circulation 4: Circulation and disinfection
9.1	[D-03]	Leaving water temperature compensation around 0°C.	R/W 0: No 1: increase 2°C, span 4°C 2: increase 4°C, span 4°C 3: increase 2°C, span 8°C 4: increase 4°C, span 8°C
9.1	[D-04]	Is a demand PCB connected?	R/W 0: No 1: Pwr consmp ctrl
9.1	[D-05]	Is the pump allowed to run if prefer. kWh rate PS is cut?	R/W 0: No 1: Yes
9.1	[D-07]	Is a solar kit connected?	R/W 0: No 1: Yes (DHW) 2: Yes (DHW + SH)
9.1	[D-08]	Is an external kWh meter used for power measurement?	R/W 0: No 1: 0,1 pulse/kWh 2: 1 pulse/kWh 3: 10 pulse/kWh 4: 100 pulse/kWh 5: 1000 pulse/kWh
9.1	[D-09]	Is an external kWh meter used for power measurement, kWh meter used for smart grid?	R/W 0: No 1: 0,1 pulse/kWh 2: 1 pulse/kWh 3: 10 pulse/kWh 4: 100 pulse/kWh 5: 1000 pulse/kWh 6: 100 pulse/kWh (PV meter) 7: 1000 pulse/kWh (PV meter)

(*1) *X*_(2) *H*_(3) *B*_(4) *EKECBUA*3V_
 (*5) *EKECBUA*6V_(6) *EKECBUA*9W_(7) BUH less_
 (*8) 300L tank_(9) E_(10) E7

Field settings table

Breadcrumb	Setting name	Range, step	Default value
9.1	[D-0A]	--	0
9.1	[D-0B]	--	2
9.1	[D-0C]	--	0
9.1	[D-0D]	--	0
9.1	[D-0E]	--	0
9.1	[E-00]	Which type of unit is installed? R/O	0~5 0: LT split
9.1	[E-01]	Which type of compressor is installed? R/O	1
9.1	[E-02]	What is the indoor unit software type? R/W (*1) R/O (*2)	0: Reversible (*1) 1: Heating only (*2)
9.1	[E-03]	What is the number of backup heater steps? R/W	0: no heater (*7) 2: 3V (*4) 3: 6V (*5) 4: 9W (*6)
9.1	[E-04]	Is the power saving function available on the outdoor unit? R/O	0: No 1: Yes
9.1	[E-05]	Can the system prepare domestic hot water? R/O	0: No 1: Yes
9.1	[E-06]	--	1
9.1	[E-07]	What kind of DHW tank is installed? R/W	0~8 0 OSO tank 150/180 1 FS with BUH 2 FS with BSH 3 OSO tank 200/250/300 4 Rotex without BSH (HYB) 5 Rotex with BSH 6 Third party tank for HYB 7 Third party tank, coil >= 1,05m2 8 Third party tank, coil >= 1,8m2
9.1	[E-08]	Power saving function for outdoor unit. R/W	0: No 1: Yes
9.1	[E-09]	--	1
9.1	[E-0B]	Is a bi-zone kit installed? R/W	0: not installed 1: - 2: Bizone kit installed
9.1	[E-0C]	What bizone system type is installed? R/W	0: Without hydraulic separator / no direct pump 1: With hydraulic separator / no direct pump 2: With hydraulic separator / with direct pump
9.1	[E-0D]	Is the system filled with glycol ? R/W	0: No 1: Yes
9.1	[E-0E]	--	0
9.1	[F-00]	Pump operation allowed outside range. R/W	0: Restricted 1: Allowed
9.1	[F-01]	Above which outdoor temperature is cooling allowed? R/W	10~35°C, step: 1°C 20°C
9.1	[F-02]	--	3
9.1	[F-03]	--	5
9.1	[F-04]	--	0
9.1	[F-05]	--	0
9.1	[F-06]	Enable Tank Boiler? R/W	0: Disabled 1: Enabled
9.1	[F-07]	Efficiency calculation R/W	0: Enabled 1: Disabled
9.1	[F-08]	Continuous heating defrost enable R/W	0: Disabled 1: Enabled
9.1	[F-09]	Pump operation during flow abnormality. R/W	0: Disabled 1: Enabled
9.1	[F-0A]	--	0
9.1	[F-0B]	Close shut-off valve during thermo OFF? R/W	0: No 1: Yes

(*1) *X* (*2) *H* (*3) *B* (*4) *EKECBUA*3V_
 (*5) *EKECBUA*6V_* (*6) *EKECBUA*9W_* (*7) BUH less_
 (*8) 300L tank_* (*9) E_* (*10) E7

Field settings table				
Breadcrumb	Setting name		Range, step	Default value
9.I	[F-0C]	Close shut-off valve during cooling?	R/W	0: No (*10) 1: Yes (*9)
9.I	[F-0D]	What is the pump operation mode?	R/W	0: Continuous 1: Sample 2: Request
9.I	[F-0E]	Tank heating support_max	R/W	10~35 kW, step: 1kW 20 kW
Bi-zone kit settings				
9.P.1	[E-0B]	Bi-zone kit installed	R/W	0: not installed 1: - 2: Bizone kit installed
9.P.2	[E-0C]	Bi-zone system type	R/W	0: Without hydraulic separator / no direct pump 1: With hydraulic separator / no direct pump 2: With hydraulic separator / with direct pump
9.P.3	[7-0A]	Add zone pump fixed PWM	R/W	20~95%, step 5% 95%
9.P.4	[7-0B]	Main zone pump fixed PWM	R/W	20~95%, step 5% 95%
9.P.5	[7-0C]	Mixing valve turning time	R/W	20~300 sec, step 5 sec 125 sec

(*1) *X_(2) *H_(3) *B_(4) *EKECBUA*3V_
 (*5) *EKECBUA*6V_(6) *EKECBUA*9W_(7) BUH less_
 (*8) 300L tank_(9) E_(10) E7